

Brand	Model	Original Cartridge
Compaq	A1000	15MX0120 No 20
Compaq	A900	12A1980 No 80
Compaq	A900	12A1985 No 85
Compaq	C3 1000	12A1980 No 80
Compaq	C3 1000	12A1985 No 85
Compaq	IJ 200	15MX0120 No 20
Compaq	IJ 300	12A1980 No 80
Compaq	IJ 300	12A1985 No 85
Compaq	IJ 600	17G0060E No 60
Compaq	IJ 650	10N0026 No 26
Compaq	IJ 650	10N0227 No 27
Compaq	IJ 700	12A1980 No 80
Compaq	IJ 700	12A1985 No 85
Compaq	IJ 750	12A1980 No 80
Compaq	IJ 750	12A1985 No 85
Compaq	IJ 900	12A1980 No 80
Compaq	IJ 900	12A1985 No 85
Compaq	LI 700	12A1980 No 80
Compaq	LI 700	12A1985 No 85
Kodak	Personal Picturemaker 100	12A1980 No 80
Kodak	Personal Picturemaker 100	12A1985 No 85
Lexmark	3000	12A1980 No 80
Lexmark	3000	12A1985 No 85
Lexmark	310	18C0035E No 35
Lexmark	310	18CX033E No 33
Lexmark	3100	15MX0120 No 20
Lexmark	3200	12A1980 No 80
Lexmark	3200	12A1985 No 85
Lexmark	410	18C0035E No 35
Lexmark	410	18CX033E No 33
Lexmark	4300	18C0035E No 35
Lexmark	4300	18CX033E No 33
Lexmark	5000	12A1980 No 80
Lexmark	5000	12A1985 No 85
Lexmark	5700	12A1980 No 80
Lexmark	5700	12A1985 No 85
Lexmark	5770	12A1980 No 80
Lexmark	5770	12A1985 No 85
Lexmark	6200	18C0035E No 35
Lexmark	6200	18CX033E No 33
Lexmark	6300	18C0035E No 35
Lexmark	6300	18CX033E No 33
Lexmark	7000	12A1980 No 80
Lexmark	7000	12A1985 No 85
Lexmark	7200	12A1980 No 80
Lexmark	7200	12A1985 No 85
Lexmark	7200V	12A1980 No 80
Lexmark	7200V	12A1985 No 85
Lexmark	910	18C0035E No 35

Lexmark	910	18CX033E No 33
Lexmark	ColorJet 3200	12A1980 No 80
Lexmark	ColorJet 3200	12A1985 No 85
Lexmark	ColorJet 5700	12A1980 No 80
Lexmark	ColorJet 5700	12A1985 No 85
Lexmark	ColorJet 5770	12A1980 No 80
Lexmark	ColorJet 5770	12A1985 No 85
Lexmark	ColorJet 7000	12A1980 No 80
Lexmark	ColorJet 7000	12A1985 No 85
Lexmark	ColorJet 7200	12A1980 No 80
Lexmark	ColorJet 7200	12A1985 No 85
Lexmark	ColorJet 7200v	12A1980 No 80
Lexmark	ColorJet 7200v	12A1985 No 85
Lexmark	F4270	15MX0120 No 20
Lexmark	Home Copier Plus	18C0035E No 35
Lexmark	Home Copier Plus	18CX033E No 33
Lexmark	i13	10N0026 No 26
Lexmark	i13	10N0227 No 27
Lexmark	Optra Color 40	12A1980 No 80
Lexmark	Optra Color 40	12A1985 No 85
Lexmark	Optra Color 40n	12A1980 No 80
Lexmark	Optra Color 40n	12A1985 No 85
Lexmark	Optra Color 45	12A1980 No 80
Lexmark	Optra Color 45	12A1985 No 85
Lexmark	P122	15MX0120 No 20
Lexmark	P3120	15MX0120 No 20
Lexmark	P315	18C0035E No 35
Lexmark	P315	18CX033E No 33
Lexmark	P3150	15MX0120 No 20
Lexmark	P4330	18C0035E No 35
Lexmark	P4330	18CX033E No 33
Lexmark	P4350	18C0035E No 35
Lexmark	P4350	18CX033E No 33
Lexmark	P450	18C0035E No 35
Lexmark	P450	18CX033E No 33
Lexmark	P6250	18C0035E No 35
Lexmark	P6250	18CX033E No 33
Lexmark	P6350	18C0035E No 35
Lexmark	P6350	18CX033E No 33
Lexmark	P700	15MX0120 No 20
Lexmark	P704	15MX0120 No 20
Lexmark	P706	15MX0120 No 20
Lexmark	P707	15MX0120 No 20
Lexmark	P708	15MX0120 No 20
Lexmark	P910	18C0035E No 35
Lexmark	P910	18CX033E No 33
Lexmark	P915	18C0035E No 35
Lexmark	P915	18CX033E No 33
Lexmark	X1100	10N0026 No 26
Lexmark	X1100	10N0227 No 27

Lexmark	X1110	10N0026 No 26
Lexmark	X1110	10N0227 No 27
Lexmark	X1130	10N0026 No 26
Lexmark	X1130	10N0227 No 27
Lexmark	X1140	10N0026 No 26
Lexmark	X1140	10N0227 No 27
Lexmark	X1150	10N0026 No 26
Lexmark	X1150	10N0227 No 27
Lexmark	X1155	10N0026 No 26
Lexmark	X1155	10N0227 No 27
Lexmark	X1160	10N0026 No 26
Lexmark	X1160	10N0227 No 27
Lexmark	X1170	10N0026 No 26
Lexmark	X1170	10N0227 No 27
Lexmark	X1180	10N0026 No 26
Lexmark	X1180	10N0227 No 27
Lexmark	X1185	10N0026 No 26
Lexmark	X1185	10N0227 No 27
Lexmark	X1190	10N0026 No 26
Lexmark	X1190	10N0227 No 27
Lexmark	X1195	10N0026 No 26
Lexmark	X1195	10N0227 No 27
Lexmark	X1200	10N0026 No 26
Lexmark	X1200	10N0227 No 27
Lexmark	X125	15MX0120 No 20
Lexmark	X1270	10N0026 No 26
Lexmark	X1270	10N0227 No 27
Lexmark	X2200	10N0026 No 26
Lexmark	X2200	10N0227 No 27
Lexmark	X2230	10N0026 No 26
Lexmark	X2230	10N0227 No 27
Lexmark	X2240	10N0026 No 26
Lexmark	X2240	10N0227 No 27
Lexmark	X2250	10N0026 No 26
Lexmark	X2250	10N0227 No 27
Lexmark	X2500	18C0035E No 35
Lexmark	X2550	18C0035E No 35
Lexmark	X3300	18C0035E No 35
Lexmark	X3300	18CX033E No 33
Lexmark	X3330	18C0035E No 35
Lexmark	X3330	18CX033E No 33
Lexmark	X3350	18C0035E No 35
Lexmark	X3350	18CX033E No 33
Lexmark	X3530	18C0035E No 35
Lexmark	X3550	18C0035E No 35
Lexmark	X4250	15MX0120 No 20
Lexmark	X4270	15MX0120 No 20
Lexmark	X4530	18C0035E No 35
Lexmark	X4550	18C0035E No 35
Lexmark	X5070	18C0035E No 35

Lexmark	X5075	18C0035E No 35
Lexmark	X5100	18L0042 No 83
Lexmark	X5130	18L0042 No 83
Lexmark	X5150	18L0042 No 83
Lexmark	X5190	18L0042 No 83
Lexmark	X5190 Pro	18L0042 No 83
Lexmark	X5210	18CX033E No 33
Lexmark	X5250	18C0035E No 35
Lexmark	X5250	18CX033E No 33
Lexmark	X5260	18C0035E No 35
Lexmark	X5260	18CX033E No 33
Lexmark	X5270	18C0035E No 35
Lexmark	X5270	18CX033E No 33
Lexmark	X5470	18C0035E No 35
Lexmark	X5470	18CX033E No 33
Lexmark	X5490	18C0035E No 35
Lexmark	X5495	18C0035E No 35
Lexmark	X6100	18L0042 No 83
Lexmark	X6150	18L0042 No 83
Lexmark	X6170	18L0042 No 83
Lexmark	X6190 Pro	18L0042 No 83
Lexmark	X63	15MX0120 No 20
Lexmark	X70	15MX0120 No 20
Lexmark	X7100	18C0035E No 35
Lexmark	X7100	18CX033E No 33
Lexmark	X7170	18C0035E No 35
Lexmark	X7170	18CX033E No 33
Lexmark	X72	10N0026 No 26
Lexmark	X72	10N0227 No 27
Lexmark	X73	15MX0120 No 20
Lexmark	X7350	18C0035E No 35
Lexmark	X7350	18CX033E No 33
Lexmark	X74	10N0026 No 26
Lexmark	X74	10N0227 No 27
Lexmark	X75	10N0026 No 26
Lexmark	X75	10N0227 No 27
Lexmark	X80	15MX0120 No 20
Lexmark	X815	18CX033E No 33
Lexmark	X83	15MX0120 No 20
Lexmark	X8300	18C0035E No 35
Lexmark	X8300	18CX033E No 33
Lexmark	X8350	18C0035E No 35
Lexmark	X8350	18CX033E No 33
Lexmark	X84	15MX0120 No 20
Lexmark	X85	15MX0120 No 20
Lexmark	X85 Pro	15MX0120 No 20
Lexmark	Z11	12A1980 No 80
Lexmark	Z11	12A1985 No 85
Lexmark	Z12	17G0060E No 60
Lexmark	Z1270	10N0026 No 26

Lexmark	Z1270	10N0227 No 27
Lexmark	Z13	10N0026 No 26
Lexmark	Z13	10N0227 No 27
Lexmark	Z1410	18C0035E No 35
Lexmark	Z1420	18C0035E No 35
Lexmark	Z22	17G0060E No 60
Lexmark	Z23	10N0026 No 26
Lexmark	Z23	10N0227 No 27
Lexmark	Z23e	10N0026 No 26
Lexmark	Z23e	10N0227 No 27
Lexmark	Z24	10N0026 No 26
Lexmark	Z24	10N0227 No 27
Lexmark	Z25	10N0026 No 26
Lexmark	Z25	10N0227 No 27
Lexmark	Z25L	10N0026 No 26
Lexmark	Z25L	10N0227 No 27
Lexmark	Z28	15MX0120 No 20
Lexmark	Z31	12A1980 No 80
Lexmark	Z31	12A1985 No 85
Lexmark	Z32	17G0060E No 60
Lexmark	Z33	10N0026 No 26
Lexmark	Z33	10N0227 No 27
Lexmark	Z34	10N0026 No 26
Lexmark	Z34	10N0227 No 27
Lexmark	Z35	10N0026 No 26
Lexmark	Z35	10N0227 No 27
Lexmark	Z42	15MX0120 No 20
Lexmark	Z43	15MX0120 No 20
Lexmark	Z44	15MX0120 No 20
Lexmark	Z45	15MX0120 No 20
Lexmark	Z45se	15MX0120 No 20
Lexmark	Z51	15MX0120 No 20
Lexmark	Z515	10N0026 No 26
Lexmark	Z515	10N0227 No 27
Lexmark	Z517	10N0026 No 26
Lexmark	Z517	10N0227 No 27
Lexmark	Z52	15MX0120 No 20
Lexmark	Z53	15MX0120 No 20
Lexmark	Z54	15MX0120 No 20
Lexmark	Z55	18L0042 No 83
Lexmark	Z55se	18L0042 No 83
Lexmark	Z600	10N0026 No 26
Lexmark	Z600	10N0227 No 27
Lexmark	Z601	10N0026 No 26
Lexmark	Z601	10N0227 No 27
Lexmark	Z602	10N0026 No 26
Lexmark	Z602	10N0227 No 27
Lexmark	Z603	10N0026 No 26
Lexmark	Z603	10N0227 No 27
Lexmark	Z604	10N0026 No 26

Lexmark	Z604	10N0227 No 27
Lexmark	Z605	10N0026 No 26
Lexmark	Z605	10N0227 No 27
Lexmark	Z611	10N0227 No 27
Lexmark	Z612	10N0026 No 26
Lexmark	Z612	10N0227 No 27
Lexmark	Z615	10N0026 No 26
Lexmark	Z615	10N0227 No 27
Lexmark	Z617	10N0026 No 26
Lexmark	Z617	10N0227 No 27
Lexmark	Z618	10N0026 No 26
Lexmark	Z618	10N0227 No 27
Lexmark	Z640	10N0227 No 27
Lexmark	Z645	10N0026 No 26
Lexmark	Z645	10N0227 No 27
Lexmark	Z65	18L0042 No 83
Lexmark	Z65 Pro	18L0042 No 83
Lexmark	Z700	15MX0120 No 20
Lexmark	Z703	15MX0120 No 20
Lexmark	Z705	15MX0120 No 20
Lexmark	Z708	15MX0120 No 20
Lexmark	Z710	15MX0120 No 20
Lexmark	Z715	15MX0120 No 20
Lexmark	Z810	18C0035E No 35
Lexmark	Z810	18CX033E No 33
Lexmark	Z812	18C0035E No 35
Lexmark	Z812	18CX033E No 33
Lexmark	Z815	18C0035E No 35
Lexmark	Z815	18CX033E No 33
Lexmark	Z816	18C0035E No 35
Lexmark	Z816	18CX033E No 33
Lexmark	Z818	18C0035E No 35
Lexmark	Z818	18CX033E No 33
Lexmark	Z82	15MX0120 No 20
Lexmark	Z845	18C0035E No 35
Lexmark	Z85	15MX0120 No 20
Samsung	MJ 4500C	12A1980 No 80
Samsung	MJ 4500C	12A1985 No 85
Samsung	Msys 4700	12A1980 No 80
Samsung	Msys 4700	12A1985 No 85
Samsung	SCX 1000 Series	15MX0120 No 20
Samsung	SCX 1150F	12A1980 No 80
Samsung	SCX 1150F	12A1985 No 85
Samsung	SF 4300	12A1980 No 80
Samsung	SF 4300	12A1985 No 85
Samsung	SF 4300C	12A1980 No 80
Samsung	SF 4300C	12A1985 No 85
Samsung	SF 4500 Series	12A1980 No 80
Samsung	SF 4500 Series	12A1985 No 85