

Brand	Model	Original Cartridge
Canon	Pixma MG2140	PG-540
Canon	Pixma MG2140	PG-540XL
Canon	Pixma MG2150	PG-540
Canon	Pixma MG2150	PG-540XL
Canon	Pixma MG2250	PG-540
Canon	Pixma MG2250	PG-540XL
Canon	Pixma MG3140	PG-540
Canon	Pixma MG3140	PG-540XL
Canon	Pixma MG3150	PG-540
Canon	Pixma MG3150	PG-540XL
Canon	Pixma MG3250	PG-540
Canon	Pixma MG3250	PG-540XL
Canon	Pixma MG3550	PG-540
Canon	Pixma MG3550	PG-540XL
Canon	Pixma MG3600	PG-540
Canon	Pixma MG3600	PG-540XL
Canon	Pixma MG3650	PG-540
Canon	Pixma MG3650	PG-540XL
Canon	Pixma MG4150	PG-540
Canon	Pixma MG4150	PG-540XL
Canon	Pixma MG4250	PG-540
Canon	Pixma MG4250	PG-540XL
Canon	Pixma MX353	PG-540
Canon	Pixma MX353	PG-540XL
Canon	Pixma MX375	PG-540
Canon	Pixma MX375	PG-540XL
Canon	Pixma MX395	PG-540
Canon	Pixma MX395	PG-540XL
Canon	Pixma MX435	PG-540
Canon	Pixma MX435	PG-540XL
Canon	Pixma MX455	PG-540
Canon	Pixma MX455	PG-540XL
Canon	Pixma MX475	PG-540
Canon	Pixma MX475	PG-540XL
Canon	Pixma MX515	PG-540
Canon	Pixma MX515	PG-540XL
Canon	Pixma MX525	PG-540
Canon	Pixma MX525	PG-540XL
Canon	Pixma MX535	PG-540
Canon	Pixma MX535	PG-540XL
Canon	Pixma TS5150 AiO	PG-540
Canon	Pixma TS5150 AiO	PG-540XL
Canon	Pixma TS5151 AiO	PG-540
Canon	Pixma TS5151 AiO	PG-540XL