

Brand	Model	Original Cartridge
Canon	Pixma MG3150	CL-541XL
Canon	Pixma MG2150	CL-541XL
Canon	Pixma MX375	CL-541XL
Canon	Pixma MX435	CL-541XL
Canon	Pixma MX515	CL-541XL
Canon	Pixma MG4150	CL-541XL
Canon	Pixma MG4250	CL-541XL
Canon	Pixma MG3250	CL-541XL
Canon	Pixma MG3150	CL-541
Canon	Pixma MG2150	CL-541
Canon	Pixma MX375	CL-541
Canon	Pixma MX435	CL-541
Canon	Pixma MX515	CL-541
Canon	Pixma MG4150	CL-541
Canon	Pixma MG4250	CL-541
Canon	Pixma MG3250	CL-541
Hewlett Packard (HP)	DeskJet	51649A No 49
Hewlett Packard (HP)	DeskWriter 500	51649A No 49
Apollo	P 2500p Series	51649A No 49
Apollo	P 2500u Series	51649A No 49
Apollo	P 2600p Series	51649A No 49
Apollo	P 2600u Series	51649A No 49
Apple	Color StyleWriter 4500	51649A No 49
Hewlett Packard (HP)	DeskJet 610 CL	51649A No 49
Hewlett Packard (HP)	DeskJet 610c	51649A No 49
Hewlett Packard (HP)	DeskJet 612c	51649A No 49
Hewlett Packard (HP)	DeskJet 630c	51649A No 49
Hewlett Packard (HP)	DeskJet 632c	51649A No 49
Hewlett Packard (HP)	DeskJet 5440	C9361E No 342
Hewlett Packard (HP)	DeskJet 640c	51649A No 49
Brother	MFC 4420C	LC700Y
Hewlett Packard (HP)	DeskJet 642c	51649A No 49
Canon	Pixma IP4600	CLI-521y
Hewlett Packard (HP)	DeskJet 648c	51649A No 49
Lexmark	S405	14N1071E No 100yw XL
Hewlett Packard (HP)	DeskJet 650c	51649A No 49
Canon	Pixma MG5450	CLI-551y
Hewlett Packard (HP)	DeskJet 656c	51649A No 49
Hewlett Packard (HP)	DeskJet 690c	51649A No 49
Hewlett Packard (HP)	DeskJet 692c	51649A No 49
Hewlett Packard (HP)	DeskJet 693c	51649A No 49
Hewlett Packard (HP)	DeskJet 694c	51649A No 49
Hewlett Packard (HP)	DeskJet 695c	51649A No 49
Hewlett Packard (HP)	DeskJet 5443	C9361E No 342
Hewlett Packard (HP)	DeskJet 695cci	51649A No 49
Brother	MFC 4820C	LC700Y
Hewlett Packard (HP)	DeskJet 697c	51649A No 49
Canon	Pixma MP630	CLI-521y
Apollo	P 2100u	51649A No 49

Lexmark	S505	14N1071E No 100yw XL
Apollo	P 2150u	51649A No 49
Canon	Pixma iP7250	CLI-551y
Apollo	P 2200	51649A No 49
Apollo	P 2250	51649A No 49
Apple	Color StyleWriter 4100	51649A No 49
Hewlett Packard (HP)	DeskJet 350	51649A No 49
Hewlett Packard (HP)	DeskJet 350c	51649A No 49
Hewlett Packard (HP)	DeskJet 350cbi	51649A No 49
Hewlett Packard (HP)	PhotoSmart 2575	C9361E No 342
Hewlett Packard (HP)	DeskJet 600	51649A No 49
Hewlett Packard (HP)	DeskJet 600c	51649A No 49
Canon	Pixma MP540	CLI-521y
Hewlett Packard (HP)	DeskJet 610	51649A No 49
Lexmark	Pro 205	14N1071E No 100yw XL
Hewlett Packard (HP)	DeskJet 612	51649A No 49
Canon	Pixma MG5550	CLI-551y
Hewlett Packard (HP)	DeskJet 656 cvr	51649A No 49
Hewlett Packard (HP)	DeskJet 660 C	51649A No 49
Hewlett Packard (HP)	DeskJet 660 Cse	51649A No 49
Hewlett Packard (HP)	DeskJet 670 TV	51649A No 49
Hewlett Packard (HP)	DeskJet 670c	51649A No 49
Hewlett Packard (HP)	DeskJet 672c	51649A No 49
Hewlett Packard (HP)	Officejet 6310 AiO	C9361E No 342
Hewlett Packard (HP)	DeskJet 680c	51649A No 49
Hewlett Packard (HP)	DeskJet 682c	51649A No 49
Canon	Pixma MX860	CLI-521y
Hewlett Packard (HP)	DeskWriter 600	51649A No 49
Lexmark	Pro 705	14N1071E No 100yw XL
Hewlett Packard (HP)	DeskWriter 600 Cse	51649A No 49
Canon	Pixma MG7150	CLI-551y
Hewlett Packard (HP)	DeskWriter 660	51649A No 49
Hewlett Packard (HP)	DeskWriter 660c	51649A No 49
Hewlett Packard (HP)	DeskWriter 680	51649A No 49
Hewlett Packard (HP)	DeskWriter 680c	51649A No 49
Hewlett Packard (HP)	DeskWriter 682c	51649A No 49
Hewlett Packard (HP)	DeskWriter 690c	51649A No 49
Hewlett Packard (HP)	Photosmart C4180	C9361E No 342
Hewlett Packard (HP)	DeskWriter 693	51649A No 49
Hewlett Packard (HP)	DeskWriter 693c	51649A No 49
Canon	Pixma MP980	CLI-521y
Hewlett Packard (HP)	DeskWriter 694	51649A No 49
Lexmark	Pro 805	14N1071E No 100yw XL
Hewlett Packard (HP)	DeskWriter 694c	51649A No 49
Hewlett Packard (HP)	OfficeJet 500	51649A No 49
Hewlett Packard (HP)	OfficeJet 520	51649A No 49
Hewlett Packard (HP)	OfficeJet 570	51649A No 49
Hewlett Packard (HP)	OfficeJet 580	51649A No 49
Hewlett Packard (HP)	OfficeJet 590	51649A No 49
Hewlett Packard (HP)	OfficeJet 600	51649A No 49

Hewlett Packard (HP)	Photosmart 7830	C9361E No 342
Hewlett Packard (HP)	OfficeJet 610	51649A No 49
Hewlett Packard (HP)	OfficeJet 630	51649A No 49
Canon	Pixma MP620	CLI-521y
Hewlett Packard (HP)	OfficeJet 635	51649A No 49
Lexmark	Pro 905	14N1071E No 100yw XL
Hewlett Packard (HP)	OfficeJet 700	51649A No 49
Hewlett Packard (HP)	OfficeJet 710	51649A No 49
Hewlett Packard (HP)	OfficeJet 720	51649A No 49
Hewlett Packard (HP)	PSC 370	51649A No 49
Hewlett Packard (HP)	PSC 380	51649A No 49
Sony	Vaio IJP-V100	51649A No 49
Hewlett Packard (HP)	DeskJet 3650	C8728A No 28
Hewlett Packard (HP)	DeskJet 3843	C8728A No 28
Hewlett Packard (HP)	DeskJet 3845	C8728A No 28
Hewlett Packard (HP)	DeskJet 450cbi	C8728A No 28
Hewlett Packard (HP)	DeskJet 450ci	C8728A No 28
Hewlett Packard (HP)	DeskJet 450wbt	C8728A No 28
Hewlett Packard (HP)	OfficeJet 4215	C8728A No 28
Hewlett Packard (HP)	PSC 1310	C8728A No 28
Hewlett Packard (HP)	PSC 1311	C8728A No 28
Hewlett Packard (HP)	PSC 1315	C8728A No 28
Hewlett Packard (HP)	DeskJet 3300	C8728A No 28
Hewlett Packard (HP)	DeskJet 3320	C8728A No 28
Lexmark	P315	18C0035E No 35
Hewlett Packard (HP)	DeskJet 3325	C8728A No 28
Hewlett Packard (HP)	Business InkJet 2250	C4813A no 11y
Hewlett Packard (HP)	DeskJet 3420	C8728A No 28
Canon	Pixma MP260	CL-513
Hewlett Packard (HP)	DeskJet 3425	C8728A No 28
Canon	Pixma MP260	CL-511
Hewlett Packard (HP)	DeskJet 3500	C8728A No 28
Canon	Pixma MG5450	CLI-551y XL
Hewlett Packard (HP)	DeskJet 3520	C8728A No 28
Hewlett Packard (HP)	DeskJet 3550	C8728A No 28
Hewlett Packard (HP)	DeskJet 3600	C8728A No 28
Hewlett Packard (HP)	DeskJet 3620	C8728A No 28
Hewlett Packard (HP)	DeskJet 3645	C8728A No 28
Hewlett Packard (HP)	DeskJet 3647	C8728A No 28
Lexmark	P4350	18C0035E No 35
Hewlett Packard (HP)	DeskJet 3651	C8728A No 28
Hewlett Packard (HP)	Business InkJet 2280	C4813A no 11y
Hewlett Packard (HP)	DeskJet 3740	C8728A No 28
Canon	Pixma MX330	CL-513
Hewlett Packard (HP)	DeskJet 3745	C8728A No 28
Canon	Pixma MX330	CL-511
Hewlett Packard (HP)	DeskJet 3840	C8728A No 28
Canon	Pixma iP7250	CLI-551y XL
Hewlett Packard (HP)	DeskJet 3847	C8728A No 28
Hewlett Packard (HP)	Fax 1240	C8728A No 28

Hewlett Packard (HP)	OfficeJet 4200	C8728A No 28
Hewlett Packard (HP)	OfficeJet 4219	C8728A No 28
Hewlett Packard (HP)	OfficeJet 4255	C8728A No 28
Hewlett Packard (HP)	PSC 1100	C8728A No 28
Lexmark	P6250	18C0035E No 35
Hewlett Packard (HP)	PSC 1213	C8728A No 28
Hewlett Packard (HP)	Business InkJet 2230	C4813A no 11y
Hewlett Packard (HP)	PSC 1215	C8728A No 28
Canon	Pixma MX320	CL-513
Hewlett Packard (HP)	PSC 1217	C8728A No 28
Canon	Pixma MX320	CL-511
Hewlett Packard (HP)	PSC 1219	C8728A No 28
Canon	Pixma MG5550	CLI-551y XL
Hewlett Packard (HP)	PSC 1317	C8728A No 28
Hewlett Packard (HP)	PSC 2108	C8728A No 28
Hewlett Packard (HP)	PSC 2170	C8728A No 28
Hewlett Packard (HP)	PSC 2171	C8728A No 28
Hewlett Packard (HP)	PSC 4110	C8728A No 28
Hewlett Packard (HP)	PSC 4215	C8728A No 28
Lexmark	P915	18C0035E No 35
Hewlett Packard (HP)	PSC 4219	C8728A No 28
Hewlett Packard (HP)	DesignJet 500	C4813A no 11y
Hewlett Packard (HP)	PSC 4255	C8728A No 28
Canon	Pixma MP250	CL-513
Hewlett Packard (HP)	OfficeJet 5610	C9352A No 22
Hewlett Packard (HP)	OfficeJet 5610v	C9352A No 22
Hewlett Packard (HP)	OfficeJet 5610xi	C9352A No 22
Hewlett Packard (HP)	PhotoSmart 5610	C9352A No 22
Hewlett Packard (HP)	PhotoSmart 5610v	C9352A No 22
Hewlett Packard (HP)	PhotoSmart 5610xi	C9352A No 22
Hewlett Packard (HP)	DeskJet 3910	C9352A No 22
Hewlett Packard (HP)	DeskJet 3915	C9352A No 22
Hewlett Packard (HP)	DeskJet 3920	C9352A No 22
Hewlett Packard (HP)	DeskJet 3930	C9352A No 22
Hewlett Packard (HP)	DeskJet 3940	C9352A No 22
Hewlett Packard (HP)	DeskJet 3940v	C9352A No 22
Lexmark	i13	10N0026 No 26
Hewlett Packard (HP)	PSC 1410	C9352A No 22
Hewlett Packard (HP)	DesignJet 800	C4913A no 82
Hewlett Packard (HP)	PSC 1410v	C9352A No 22
Brother	DCP 165C	LC980Y
Hewlett Packard (HP)	PSC 1410xi	C9352A No 22
Canon	Pixma MG8150	CLI-526y
Hewlett Packard (HP)	PSC 1417	C9352A No 22
Canon	Pixma MG2550	CL-546
Hewlett Packard (HP)	DeskJet D1311	C9352A No 22
Hewlett Packard (HP)	DeskJet D1320	C9352A No 22
Hewlett Packard (HP)	DeskJet D1330	C9352A No 22
Hewlett Packard (HP)	DeskJet D1341	C9352A No 22
Hewlett Packard (HP)	DeskJet D1360	C9352A No 22

Hewlett Packard (HP)	DeskJet D1368	C9352A No 22
Lexmark	X1100	10N0026 No 26
Hewlett Packard (HP)	DeskJet D2320	C9352A No 22
Hewlett Packard (HP)	DeskJet D2330	C9352A No 22
Brother	MFC 250C	LC980Y
Hewlett Packard (HP)	DeskJet D2345	C9352A No 22
Canon	Pixma MG5150	CLI-526y
Hewlett Packard (HP)	DeskJet D2360	C9352A No 22
Hewlett Packard (HP)	DeskJet D2368	C9352A No 22
Hewlett Packard (HP)	DeskJet D2400	C9352A No 22
Hewlett Packard (HP)	DeskJet F310	C9352A No 22
Hewlett Packard (HP)	DeskJet F325	C9352A No 22
Hewlett Packard (HP)	DeskJet F335	C9352A No 22
Hewlett Packard (HP)	DeskJet F340	C9352A No 22
Lexmark	X1110	10N0026 No 26
Hewlett Packard (HP)	DeskJet F350	C9352A No 22
Hewlett Packard (HP)	DeskJet F370	C9352A No 22
Brother	MFC 290C	LC980Y
Hewlett Packard (HP)	DeskJet F378	C9352A No 22
Canon	Pixma MG5250	CLI-526y
Hewlett Packard (HP)	DeskJet F380	C9352A No 22
Hewlett Packard (HP)	DeskJet F385	C9352A No 22
Hewlett Packard (HP)	DeskJet F388	C9352A No 22
Hewlett Packard (HP)	DeskJet F390	C9352A No 22
Hewlett Packard (HP)	DeskJet F394	C9352A No 22
Hewlett Packard (HP)	OfficeJet 4355	C9352A No 22
Hewlett Packard (HP)	PSC 1400	C9352A No 22
Lexmark	X1130	10N0026 No 26
Hewlett Packard (HP)	PSC 1402	C9352A No 22
Hewlett Packard (HP)	PSC 1415	C9352A No 22
Brother	DCP 375CW	LC980Y
Hewlett Packard (HP)	PSC 1401	C9352A No 22
Canon	Pixma MG6150	CLI-526y
Hewlett Packard (HP)	PSC 1403	C9352A No 22
Hewlett Packard (HP)	PSC 1406	C9352A No 22
Hewlett Packard (HP)	PSC 1408	C9352A No 22
Hewlett Packard (HP)	OfficeJet 4315	C9352A No 22
Hewlett Packard (HP)	OfficeJet 5600	C9352A No 22
Hewlett Packard (HP)	DeskJet D1460	C9352A No 22
Hewlett Packard (HP)	DeskJet D2460	C9352A No 22
Lexmark	X1140	10N0026 No 26
Hewlett Packard (HP)	DeskJet F2180	C9352A No 22
Hewlett Packard (HP)	DeskJet F4180	C9352A No 22
Brother	DCP 195C	LC980Y
Hewlett Packard (HP)	PhotoSmart 3110	C9352A No 22
Canon	Pixma MG5350	CLI-526y
Hewlett Packard (HP)	DeskJet F4172	C9352A No 22
Hewlett Packard (HP)	OfficeJet J3680	C9352A No 22
Hewlett Packard (HP)	DeskJet D1560	C9352A No 22
Hewlett Packard (HP)	DeskJet F2280	C9352A No 22

Hewlett Packard (HP)	Deskjet F4100	C9352A No 22
Hewlett Packard (HP)	DeskJet D1520	C9352A No 22
Hewlett Packard (HP)	DeskJet 450cbi	C6657A No 57
Hewlett Packard (HP)	DeskJet 450ci	C6657A No 57
Hewlett Packard (HP)	DeskJet 450wbt	C6657A No 57
Hewlett Packard (HP)	DeskJet 5150	C6657A No 57
Hewlett Packard (HP)	DeskJet 5550	C6657A No 57
Hewlett Packard (HP)	DeskJet 5551	C6657A No 57
Hewlett Packard (HP)	DeskJet 5650	C6657A No 57
Hewlett Packard (HP)	DeskJet 9650	C6657A No 57
Hewlett Packard (HP)	DeskJet 9670	C6657A No 57
Hewlett Packard (HP)	DeskJet 9680	C6657A No 57
Hewlett Packard (HP)	Digital Copier Printer 410	C6657A No 57
Hewlett Packard (HP)	OfficeJet 4215	C6657A No 57
Lexmark	i13	10N0227 No 27
Hewlett Packard (HP)	OfficeJet 6110	C6657A No 57
Hewlett Packard (HP)	Officejet Pro K550dtn	C9393A No 88yw
Hewlett Packard (HP)	PhotoSmart 7150	C6657A No 57
Brother	DCP 585C	LC1100Y
Hewlett Packard (HP)	PhotoSmart 7260	C6657A No 57
Brother	DCP J315W	LC985Y
Hewlett Packard (HP)	PhotoSmart 7350	C6657A No 57
Canon	Pixma MG2550	CL-546XL
Hewlett Packard (HP)	PhotoSmart 7450	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 7450v	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 7450xi	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 7550	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 7660	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 7755	C6657A No 57
Lexmark	X1100	10N0227 No 27
Hewlett Packard (HP)	PhotoSmart 7760	C6657A No 57
Hewlett Packard (HP)	Officejet Pro K550dtwn	C9393A No 88yw
Hewlett Packard (HP)	PhotoSmart 7960	C6657A No 57
Brother	DCP 6690CW	LC1100Y
Hewlett Packard (HP)	PSC 1310	C6657A No 57
Brother	DCP J515W	LC985Y
Hewlett Packard (HP)	PSC 1311	C6657A No 57
Hewlett Packard (HP)	PSC 1315	C6657A No 57
Hewlett Packard (HP)	PSC 1340	C6657A No 57
Hewlett Packard (HP)	PSC 1350	C6657A No 57
Hewlett Packard (HP)	PSC 2110	C6657A No 57
Hewlett Packard (HP)	PSC 2110v	C6657A No 57
Hewlett Packard (HP)	PSC 2110xi	C6657A No 57
Lexmark	X1110	10N0227 No 27
Hewlett Packard (HP)	PSC 2175	C6657A No 57
Hewlett Packard (HP)	Officejet Pro L7000	C9393A No 88yw
Hewlett Packard (HP)	PSC 2210	C6657A No 57
Brother	MFC 6490CW	LC1100Y
Hewlett Packard (HP)	PSC 2410 PhotoSmart	C6657A No 57
Brother	DCP J715W	LC985Y

Hewlett Packard (HP)	PSC 2510 PhotoSmart	C6657A No 57
Hewlett Packard (HP)	DeskJet 450	C6657A No 57
Hewlett Packard (HP)	DeskJet 5151	C6657A No 57
Hewlett Packard (HP)	DeskJet 5552	C6657A No 57
Hewlett Packard (HP)	DeskJet 5600	C6657A No 57
Hewlett Packard (HP)	DeskJet 5652	C6657A No 57
Hewlett Packard (HP)	DeskJet 5655	C6657A No 57
Lexmark	X1130	10N0227 No 27
Hewlett Packard (HP)	DeskJet 5850	C6657A No 57
Hewlett Packard (HP)	Officejet Pro K5400	C9393A No 88yw
Hewlett Packard (HP)	DeskJet 6110	C6657A No 57
Brother	MFC 790CW	LC1100Y
Hewlett Packard (HP)	DeskJet 7762	C6657A No 57
Brother	DCP J140W	LC985Y
Hewlett Packard (HP)	DeskJet 9600	C6657A No 57
Hewlett Packard (HP)	Digital Copier 410	C6657A No 57
Hewlett Packard (HP)	Fax 1240	C6657A No 57
Hewlett Packard (HP)	OfficeJet 4110	C6657A No 57
Hewlett Packard (HP)	OfficeJet 4200	C6657A No 57
Hewlett Packard (HP)	OfficeJet 4219	C6657A No 57
Hewlett Packard (HP)	OfficeJet 4255	C6657A No 57
Lexmark	X1140	10N0227 No 27
Hewlett Packard (HP)	OfficeJet 5500	C6657A No 57
Hewlett Packard (HP)	Officejet Pro K5400dn	C9393A No 88yw
Hewlett Packard (HP)	OfficeJet 5505	C6657A No 57
Brother	MFC 5490CN	LC1100Y
Hewlett Packard (HP)	OfficeJet 5510	C6657A No 57
Brother	MFC J220	LC985Y
Hewlett Packard (HP)	OfficeJet 5515	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 100	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 130	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 140	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 145	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 230	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 240	C6657A No 57
Lexmark	X1150	10N0227 No 27
Hewlett Packard (HP)	PhotoSmart 2410	C6657A No 57
Hewlett Packard (HP)	Officejet Pro K5400dtn	C9393A No 88yw
Hewlett Packard (HP)	PhotoSmart 245	C6657A No 57
Brother	MFC 490CW	LC1100Y
Hewlett Packard (HP)	PhotoSmart 2500	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 2510	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 7200	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 7345	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 7400 Series	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 7600	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 7700	C6657A No 57
Hewlett Packard (HP)	PhotoSmart 7762	C6657A No 57
Lexmark	X1155	10N0227 No 27
Hewlett Packard (HP)	PhotoSmart 7900	C6657A No 57

Hewlett Packard (HP)	Officejet Pro L7500	C9393A No 88yw
Hewlett Packard (HP)	PhotoSmart P145	C6657A No 57
Hewlett Packard (HP)	PhotoSmart P230	C6657A No 57
Hewlett Packard (HP)	PhotoSmart P7150	C6657A No 57
Hewlett Packard (HP)	PSC 1100	C6657A No 57
Hewlett Packard (HP)	PSC 1110	C6657A No 57
Hewlett Packard (HP)	PSC 1200	C6657A No 57
Hewlett Packard (HP)	PSC 1205	C6657A No 57
Hewlett Packard (HP)	PSC 1209	C6657A No 57
Hewlett Packard (HP)	PSC 1210	C6657A No 57
Lexmark	X1160	10N0227 No 27
Hewlett Packard (HP)	PSC 1213	C6657A No 57
Hewlett Packard (HP)	Officejet Pro L7680	C9393A No 88yw
Hewlett Packard (HP)	PSC 1215	C6657A No 57
Hewlett Packard (HP)	PSC 1217	C6657A No 57
Hewlett Packard (HP)	PSC 1219	C6657A No 57
Hewlett Packard (HP)	PSC 1300	C6657A No 57
Hewlett Packard (HP)	PSC 1317	C6657A No 57
Hewlett Packard (HP)	PSC 1355	C6657A No 57
Hewlett Packard (HP)	PSC 2108	C6657A No 57
Hewlett Packard (HP)	PSC 2115	C6657A No 57
Hewlett Packard (HP)	PSC 2170	C6657A No 57
Lexmark	X1170	10N0227 No 27
Hewlett Packard (HP)	PSC 2171	C6657A No 57
Hewlett Packard (HP)	Officejet Pro L7780	C9393A No 88yw
Hewlett Packard (HP)	PSC 2179	C6657A No 57
Hewlett Packard (HP)	PSC 2410	C6657A No 57
Hewlett Packard (HP)	PSC 2510	C6657A No 57
Hewlett Packard (HP)	PSC 2550	C6657A No 57
Hewlett Packard (HP)	PSC 4110	C6657A No 57
Hewlett Packard (HP)	PSC 4215	C6657A No 57
Hewlett Packard (HP)	PSC 4219	C6657A No 57
Hewlett Packard (HP)	PSC 4255	C6657A No 57
Hewlett Packard (HP)	DeskJet F4172	C6657A No 57
Lexmark	X1185	10N0227 No 27
Hewlett Packard (HP)	DeskJet 460c	C8766E No 343
Hewlett Packard (HP)	DeskJet 460cb	C8766E No 343
Hewlett Packard (HP)	DeskJet 460wbt	C8766E No 343
Hewlett Packard (HP)	PhotoSmart 8050	C8766E No 343
Hewlett Packard (HP)	PhotoSmart 8153	C8766E No 343
Hewlett Packard (HP)	PhotoSmart 8453	C8766E No 343
Hewlett Packard (HP)	DeskJet 460	C8766E No 343
Hewlett Packard (HP)	DeskJet 5943	C8766E No 343
Hewlett Packard (HP)	DeskJet 6800	C8766E No 343
Hewlett Packard (HP)	DeskJet 6848	C8766E No 343
Hewlett Packard (HP)	OfficeJet 6200	C8766E No 343
Hewlett Packard (HP)	OfficeJet 6205	C8766E No 343
Lexmark	X5130	18L0042 No 83
Hewlett Packard (HP)	PhotoSmart 2570	C8766E No 343
Brother	DCP 330C	LC1000Y

Hewlett Packard (HP)	PhotoSmart 2600	C8766E No 343
Canon	Pixma IP2500	CL-38
Hewlett Packard (HP)	PhotoSmart 2700	C8766E No 343
Brother	DCP J725W	LC1220Y
Hewlett Packard (HP)	PSC 1500	C8766E No 343
Hewlett Packard (HP)	PSC 1510	C8766E No 343
Hewlett Packard (HP)	PSC 1600	C8766E No 343
Hewlett Packard (HP)	PSC 1610	C8766E No 343
Hewlett Packard (HP)	PSC 2350	C8766E No 343
Hewlett Packard (HP)	PSC 2353	C8766E No 343
Hewlett Packard (HP)	PSC 2575	C8766E No 343
Lexmark	X5150	18L0042 No 83
Hewlett Packard (HP)	PSC 2610	C8766E No 343
Brother	DCP 540CN	LC1000Y
Hewlett Packard (HP)	PSC 2700	C8766E No 343
Canon	Pixma IP1800	CL-38
Hewlett Packard (HP)	DeskJet 5740	C8766E No 343
Brother	DCP J925W	LC1220Y
Hewlett Packard (HP)	DeskJet 5745	C8766E No 343
Hewlett Packard (HP)	DeskJet 5940	C8766E No 343
Hewlett Packard (HP)	DeskJet 6520	C8766E No 343
Hewlett Packard (HP)	DeskJet 6540	C8766E No 343
Hewlett Packard (HP)	DeskJet 6543	C8766E No 343
Hewlett Packard (HP)	DeskJet 6620	C8766E No 343
Hewlett Packard (HP)	DeskJet 6840	C8766E No 343
Lexmark	X5190	18L0042 No 83
Hewlett Packard (HP)	DeskJet 6843	C8766E No 343
Brother	DCP 750CW	LC1000Y
Hewlett Packard (HP)	DeskJet 9800	C8766E No 343
Canon	Pixma MP210	CL-38
Hewlett Packard (HP)	OfficeJet 6210	C8766E No 343
Brother	MFC J430W	LC1220Y
Hewlett Packard (HP)	OfficeJet 7210	C8766E No 343
Hewlett Packard (HP)	OfficeJet 7310	C8766E No 343
Hewlett Packard (HP)	OfficeJet 7410	C8766E No 343
Hewlett Packard (HP)	PhotoSmart 2575	C8766E No 343
Hewlett Packard (HP)	PhotoSmart 2610	C8766E No 343
Hewlett Packard (HP)	PhotoSmart 2710	C8766E No 343
Hewlett Packard (HP)	PhotoSmart 8150	C8766E No 343
Lexmark	X5190 Pro	18L0042 No 83
Hewlett Packard (HP)	PhotoSmart 8450	C8766E No 343
Brother	FAX 1360	LC1000Y
Hewlett Packard (HP)	PhotoSmart 8450GP	C8766E No 343
Canon	Pixma MP220	CL-38
Hewlett Packard (HP)	PhotoSmart 8750	C8766E No 343
Hewlett Packard (HP)	PSC 2355	C8766E No 343
Hewlett Packard (HP)	DeskJet 6940	C8766E No 343
Hewlett Packard (HP)	DeskJet 6980	C8766E No 343
Hewlett Packard (HP)	Officejet 6310 AiO	C8766E No 343
Hewlett Packard (HP)	PhotoSmart 320	C8766E No 343

Hewlett Packard (HP)	PhotoSmart 325	C8766E No 343
Hewlett Packard (HP)	PhotoSmart 335	C8766E No 343
Lexmark	X6100	18L0042 No 83
Hewlett Packard (HP)	PhotoSmart 370	C8766E No 343
Brother	FAX 1460	LC1000Y
Hewlett Packard (HP)	PhotoSmart 375	C8766E No 343
Canon	Pixma MX310	CL-38
Hewlett Packard (HP)	PhotoSmart 385	C8766E No 343
Hewlett Packard (HP)	Photosmart C4180	C8766E No 343
Hewlett Packard (HP)	PhotoSmart 428	C8766E No 343
Hewlett Packard (HP)	PhotoSmart 475	C8766E No 343
Hewlett Packard (HP)	PhotoSmart B8350	C8766E No 343
Hewlett Packard (HP)	PhotoSmart C3100 All-in-	C8766E No 343
Hewlett Packard (HP)	Photosmart C3180	C8766E No 343
Hewlett Packard (HP)	PhotoSmart D5160	C8766E No 343
Lexmark	X6150	18L0042 No 83
Hewlett Packard (HP)	PhotoSmart P320	C8766E No 343
Brother	FAX 1560	LC1000Y
Hewlett Packard (HP)	PhotoSmart P325	C8766E No 343
Canon	Pixma MP140	CL-38
Hewlett Packard (HP)	Photosmart C3183	C8766E No 343
Hewlett Packard (HP)	PhotoSmart Pro B8350	C8766E No 343
Hewlett Packard (HP)	OfficeJet K7100	C8766E No 343
Hewlett Packard (HP)	DeskJet H470	C8766E No 343
Hewlett Packard (HP)	OfficeJet H470	C8766E No 343
Hewlett Packard (HP)	Officejet 100	C8766E No 343
Hewlett Packard (HP)	DeskJet 460c	C9363E No 344
Hewlett Packard (HP)	DeskJet 460cb	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 2613	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 2713	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 8050	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 8153	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 8453	C9363E No 344
Hewlett Packard (HP)	DeskJet 460	C9363E No 344
Hewlett Packard (HP)	DeskJet 5943	C9363E No 344
Hewlett Packard (HP)	DeskJet 6800	C9363E No 344
Hewlett Packard (HP)	DeskJet 6848	C9363E No 344
Hewlett Packard (HP)	OfficeJet 6200	C9363E No 344
Compaq	C3 1000	12A1980 No 80
Hewlett Packard (HP)	OfficeJet 6205	C9363E No 344
Hewlett Packard (HP)	Photosmart C4280	CB337EE No 351
Hewlett Packard (HP)	PhotoSmart 2570	C9363E No 344
Hewlett Packard (HP)	DeskJet D5560	CC644EE No 300xl
Hewlett Packard (HP)	PhotoSmart 2600	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 2700	C9363E No 344
Hewlett Packard (HP)	PSC 1600	C9363E No 344
Hewlett Packard (HP)	PSC 1610	C9363E No 344
Hewlett Packard (HP)	PSC 2350	C9363E No 344
Hewlett Packard (HP)	PSC 2353	C9363E No 344
Hewlett Packard (HP)	PSC 2575	C9363E No 344

Hewlett Packard (HP)	PSC 2610	C9363E No 344
Compaq	IJ 300	12A1980 No 80
Hewlett Packard (HP)	PSC 2700	C9363E No 344
Hewlett Packard (HP)	DeskJet D4260	CB337EE No 351
Hewlett Packard (HP)	DeskJet 5740	C9363E No 344
Hewlett Packard (HP)	PhotoSmart C4680 AIO	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet 5745	C9363E No 344
Hewlett Packard (HP)	DeskJet 5940	C9363E No 344
Hewlett Packard (HP)	DeskJet 6520	C9363E No 344
Hewlett Packard (HP)	DeskJet 6540	C9363E No 344
Hewlett Packard (HP)	DeskJet 6543	C9363E No 344
Hewlett Packard (HP)	DeskJet 6620	C9363E No 344
Hewlett Packard (HP)	DeskJet 6840	C9363E No 344
Hewlett Packard (HP)	DeskJet 6843	C9363E No 344
Compaq	IJ 700	12A1980 No 80
Hewlett Packard (HP)	DeskJet 9800	C9363E No 344
Hewlett Packard (HP)	Photosmart C5280	CB337EE No 351
Hewlett Packard (HP)	OfficeJet 6210	C9363E No 344
Hewlett Packard (HP)	DeskJet D1660	CC644EE No 300xl
Hewlett Packard (HP)	OfficeJet 7210	C9363E No 344
Hewlett Packard (HP)	OfficeJet 7310	C9363E No 344
Hewlett Packard (HP)	OfficeJet 7410	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 2575	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 2610	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 2710	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 8150	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 8450	C9363E No 344
Compaq	IJ 750	12A1980 No 80
Hewlett Packard (HP)	PhotoSmart 8450GP	C9363E No 344
Hewlett Packard (HP)	OfficeJet 5700	CB337EE No 351
Hewlett Packard (HP)	PhotoSmart 8750	C9363E No 344
Hewlett Packard (HP)	DeskJet D2660	CC644EE No 300xl
Hewlett Packard (HP)	PSC 2355	C9363E No 344
Hewlett Packard (HP)	DeskJet 6940	C9363E No 344
Hewlett Packard (HP)	DeskJet 6980	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 320	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 325	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 335	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 370	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 375	C9363E No 344
Compaq	IJ 900	12A1980 No 80
Hewlett Packard (HP)	PhotoSmart 385	C9363E No 344
Hewlett Packard (HP)	Photosmart C4472	CB337EE No 351
Hewlett Packard (HP)	PhotoSmart 420	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 428	C9363E No 344
Hewlett Packard (HP)	PhotoSmart 475	C9363E No 344
Hewlett Packard (HP)	PhotoSmart B8350	C9363E No 344
Hewlett Packard (HP)	PhotoSmart D5160	C9363E No 344
Hewlett Packard (HP)	PhotoSmart P320	C9363E No 344
Hewlett Packard (HP)	DeskJet 9800d	C9363E No 344

Hewlett Packard (HP)	Photosmart 422	C9363E No 344
Hewlett Packard (HP)	Photosmart 8750gp	C9363E No 344
Compaq	LI 700	12A1980 No 80
Hewlett Packard (HP)	Officejet 6215	C9363E No 344
Hewlett Packard (HP)	Photosmart C4200	CB337EE No 351
Hewlett Packard (HP)	PSC 2355p	C9363E No 344
Hewlett Packard (HP)	PhotoSmart C4780 AIO	CC644EE No 300xl
Hewlett Packard (HP)	PhotoSmart Pro B8350	C9363E No 344
Hewlett Packard (HP)	OfficeJet K7100	C9363E No 344
Hewlett Packard (HP)	Photosmart C8180	C9363E No 344
Hewlett Packard (HP)	DeskJet H470	C9363E No 344
Hewlett Packard (HP)	OfficeJet H470	C9363E No 344
Hewlett Packard (HP)	Officejet 100	C9363E No 344
Canon	MX 300	CL-41
Canon	Pixma IP1200	CL-41
Canon	Pixma IP1600	CL-41
Canon	Pixma IP2200	CL-41
Canon	Pixma MP150	CL-41
Canon	Pixma MP170	CL-41
Canon	Pixma MP450	CL-41
Canon	Pixma IP6210D	CL-41
Canon	Pixma IP6220D	CL-41
Canon	Pixma MP160	CL-41
Canon	Pixma MP180	CL-41
Canon	Pixma MP460	CL-41
Lexmark	Z12	17G0060E No 60
Canon	Pixma IP1300	CL-41
Hewlett Packard (HP)	Photosmart C4280	CB338EE No 351xl
Canon	Pixma IP1700	CL-41
Canon	Pixma IP2400	CL-41
Canon	Pixma IP2500	CL-41
Canon	Pixma IP1800	CL-41
Canon	Pixma MP210	CL-41
Canon	Pixma MP310	CL-41
Canon	Pixma MP220	CL-41
Canon	Pixma MX310	CL-41
Canon	Pixma MP140	CL-41
Lexmark	Z22	17G0060E No 60
Canon	Pixma IP1900	CL-41
Hewlett Packard (HP)	DeskJet D4260	CB338EE No 351xl
Canon	Pixma IP2600	CL-41
Canon	Pixma MP190	CL-41
Canon	Pixma MX300	CL-41
Canon	MX 300	CL-51
Canon	Pixma IP2200	CL-51
Canon	Pixma MP150	CL-51
Canon	Pixma MP170	CL-51
Canon	Pixma MP450	CL-51
Canon	Pixma IP6210D	CL-51
Canon	Pixma IP6220D	CL-51

Canon	Pixma MP160	CL-51
Canon	Pixma MP180	CL-51
Canon	Pixma MP460	CL-51
Canon	Pixma IP2400	CL-51
Canon	Pixma MX310	CL-51
Brother	MFC 3220C	LC800Y
Canon	Pixma MP140	CL-51
Brother	DCP 150C	LC970Y
Canon	Pixma MX300	CL-51
Hewlett Packard (HP)	DeskJet D1330	C9352CE No 22XL
Lexmark	Home Copier Plus	18CX033E No 33
Lexmark	P315	18CX033E No 33
Lexmark	P4350	18CX033E No 33
Lexmark	P6250	18CX033E No 33
Lexmark	P915	18CX033E No 33
Lexmark	X3330	18CX033E No 33
Lexmark	X3350	18CX033E No 33
Lexmark	X5210	18CX033E No 33
Lexmark	X5250	18CX033E No 33
Lexmark	X5260	18CX033E No 33
Lexmark	X5270	18CX033E No 33
Lexmark	X7170	18CX033E No 33
Brother	DCP 115C	LC900Y
Lexmark	X815	18CX033E No 33
Hewlett Packard (HP)	F4280 All in one	CC643EE No 300
Lexmark	Z810	18CX033E No 33
Hewlett Packard (HP)	OfficeJet Pro 8000	C4909AE No 940XL
Lexmark	Z812	18CX033E No 33
Lexmark	Z815	18CX033E No 33
Lexmark	Z816	18CX033E No 33
Lexmark	Z818	18CX033E No 33
Lexmark	P910	18CX033E No 33
Lexmark	P4330	18CX033E No 33
Lexmark	P6350	18CX033E No 33
Lexmark	X7350	18CX033E No 33
Brother	DCP 120C	LC900Y
Lexmark	X8350	18CX033E No 33
Hewlett Packard (HP)	Deskjet F4200 All in one	CC643EE No 300
Lexmark	P450	18CX033E No 33
Lexmark	X5470	18CX033E No 33
Lexmark	910	18CX033E No 33
Lexmark	310	18CX033E No 33
Lexmark	410	18CX033E No 33
Lexmark	X7100	18CX033E No 33
Lexmark	X8300	18CX033E No 33
Lexmark	X3300	18CX033E No 33
Lexmark	4300	18CX033E No 33
Brother	DCP 310CN	LC900Y
Lexmark	6300	18CX033E No 33
Hewlett Packard (HP)	DeskJet F4210 All in one	CC643EE No 300

Lexmark	6200	18CX033E No 33
Canon	Pixma IP4200	CLI-8y
Canon	Pixma IP5200	CLI-8y
Canon	Pixma IP5200R	CLI-8y
Canon	Pixma MP500	CLI-8y
Canon	Pixma MP800	CLI-8y
Canon	Pixma IP6600D	CLI-8y
Canon	Pixma MP510	CLI-8y
Canon	Pixma MP600	CLI-8y
Canon	Pixma MP600R	CLI-8y
Canon	Pixma MP810	CLI-8y
Canon	Pixma MP530	CLI-8y
Canon	Pixma MP830	CLI-8y
Brother	MFC 3200C	LC600Y
Canon	Pixma IP3300	CLI-8y
Hewlett Packard (HP)	PhotoSmart C6300 All in d	CB320E No 364yw
Canon	Pixma IP4300	CLI-8y
Lexmark	S405	14N0902E No 100yw
Canon	Pixma IP5300	CLI-8y
Canon	Pixma IP6700D	CLI-8y
Canon	Pixma iX4000	CLI-8y
Canon	Pixma iX5000	CLI-8y
Canon	Pixma Pro9000	CLI-8y
Canon	Pixma MP950	CLI-8y
Canon	Pixma IP5100	CLI-8y
Canon	Pixma IP4500	CLI-8y
Brother	MFC 5100C	LC600Y
Canon	Pixma MP520	CLI-8y
Hewlett Packard (HP)	PhotoSmart D5460	CB320E No 364yw
Canon	Pixma MP610	CLI-8y
Lexmark	S505	14N0902E No 100yw
Canon	Pixma MX700	CLI-8y
Canon	Pixma IP3500	CLI-8y
Canon	Pixma MP970	CLI-8y
Canon	Pixma MX850	CLI-8y
Hewlett Packard (HP)	PhotoSmart 2570	C9361E No 342
Hewlett Packard (HP)	Photosmart 7850	C9361E No 342
Hewlett Packard (HP)	PhotoSmart C3100 All-in-d	C9361E No 342
Hewlett Packard (HP)	Photosmart C3180	C9361E No 342
Hewlett Packard (HP)	PSC 1507 All-In-One	C9361E No 342
Hewlett Packard (HP)	PSC 1508	C9361E No 342
Hewlett Packard (HP)	PSC 1510 All-In-One	C9361E No 342
Hewlett Packard (HP)	PSC 1513 All-In-One	C9361E No 342
Hewlett Packard (HP)	Photosmart C3183	C9361E No 342
Lexmark	Home Copier Plus	18C0035E No 35
Lexmark	X3330	18C0035E No 35
Lexmark	X3350	18C0035E No 35
Lexmark	X5250	18C0035E No 35
Lexmark	X5260	18C0035E No 35
Lexmark	X5270	18C0035E No 35

Lexmark	X7170	18C0035E No 35
Lexmark	Z810	18C0035E No 35
Lexmark	Z812	18C0035E No 35
Lexmark	Z815	18C0035E No 35
Lexmark	Z816	18C0035E No 35
Lexmark	Z818	18C0035E No 35
Lexmark	P910	18C0035E No 35
Lexmark	P4330	18C0035E No 35
Lexmark	P6350	18C0035E No 35
Lexmark	X7350	18C0035E No 35
Lexmark	X8350	18C0035E No 35
Lexmark	P450	18C0035E No 35
Lexmark	X5470	18C0035E No 35
Lexmark	Z1420	18C0035E No 35
Lexmark	X3550	18C0035E No 35
Lexmark	Z1410	18C0035E No 35
Lexmark	X3530	18C0035E No 35
Lexmark	X4530	18C0035E No 35
Lexmark	X4550	18C0035E No 35
Lexmark	Z845	18C0035E No 35
Lexmark	X2550	18C0035E No 35
Lexmark	X2500	18C0035E No 35
Lexmark	X5070	18C0035E No 35
Lexmark		910 18C0035E No 35
Lexmark		310 18C0035E No 35
Lexmark		410 18C0035E No 35
Lexmark	X7100	18C0035E No 35
Lexmark	X8300	18C0035E No 35
Lexmark	X3300	18C0035E No 35
Lexmark		4300 18C0035E No 35
Lexmark		6300 18C0035E No 35
Lexmark		6200 18C0035E No 35
Lexmark	X5490	18C0035E No 35
Lexmark	X5075	18C0035E No 35
Compaq	IJ 650	10N0026 No 26
Lexmark	X1150	10N0026 No 26
Lexmark	X1155	10N0026 No 26
Lexmark	X1160	10N0026 No 26
Lexmark	X1170	10N0026 No 26
Lexmark	X1185	10N0026 No 26
Lexmark	X1190	10N0026 No 26
Lexmark	X1195	10N0026 No 26
Lexmark	X2230	10N0026 No 26
Lexmark	X2240	10N0026 No 26
Lexmark	X2250	10N0026 No 26
Lexmark	X72	10N0026 No 26
Lexmark	X74	10N0026 No 26
Lexmark	X75	10N0026 No 26
Lexmark	Z13	10N0026 No 26
Lexmark	Z23	10N0026 No 26

Lexmark	Z23e	10N0026 No 26
Lexmark	Z24	10N0026 No 26
Lexmark	Z25	10N0026 No 26
Lexmark	Z25L	10N0026 No 26
Lexmark	Z33	10N0026 No 26
Lexmark	Z34	10N0026 No 26
Lexmark	Z35	10N0026 No 26
Lexmark	Z515	10N0026 No 26
Lexmark	Z517	10N0026 No 26
Lexmark	Z600	10N0026 No 26
Lexmark	Z601	10N0026 No 26
Lexmark	Z602	10N0026 No 26
Lexmark	Z603	10N0026 No 26
Lexmark	Z604	10N0026 No 26
Lexmark	Z605	10N0026 No 26
Lexmark	Z612	10N0026 No 26
Lexmark	Z615	10N0026 No 26
Lexmark	Z617	10N0026 No 26
Lexmark	Z645	10N0026 No 26
Lexmark	Z1270	10N0026 No 26
Lexmark	X1270	10N0026 No 26
Lexmark	Z618	10N0026 No 26
Lexmark	X2200	10N0026 No 26
Lexmark	X1200	10N0026 No 26
Lexmark	X1180	10N0026 No 26
Compaq	IJ 650	10N0227 No 27
Lexmark	X1190	10N0227 No 27
Lexmark	X1195	10N0227 No 27
Lexmark	X2230	10N0227 No 27
Lexmark	X2240	10N0227 No 27
Lexmark	X2250	10N0227 No 27
Lexmark	X72	10N0227 No 27
Lexmark	X74	10N0227 No 27
Lexmark	X75	10N0227 No 27
Lexmark	Z13	10N0227 No 27
Lexmark	Z23	10N0227 No 27
Lexmark	Z23e	10N0227 No 27
Lexmark	Z24	10N0227 No 27
Lexmark	Z25	10N0227 No 27
Lexmark	Z25L	10N0227 No 27
Lexmark	Z33	10N0227 No 27
Lexmark	Z34	10N0227 No 27
Lexmark	Z35	10N0227 No 27
Lexmark	Z515	10N0227 No 27
Lexmark	Z517	10N0227 No 27
Lexmark	Z600	10N0227 No 27
Lexmark	Z601	10N0227 No 27
Lexmark	Z602	10N0227 No 27
Lexmark	Z603	10N0227 No 27
Lexmark	Z604	10N0227 No 27

Lexmark	Z605	10N0227 No 27
Lexmark	Z612	10N0227 No 27
Lexmark	Z615	10N0227 No 27
Lexmark	Z617	10N0227 No 27
Lexmark	Z645	10N0227 No 27
Lexmark	Z1270	10N0227 No 27
Lexmark	X1270	10N0227 No 27
Lexmark	Z611	10N0227 No 27
Lexmark	Z618	10N0227 No 27
Lexmark	X2200	10N0227 No 27
Lexmark	X1200	10N0227 No 27
Lexmark	X1180	10N0227 No 27
Lexmark	Z640	10N0227 No 27
Lexmark	X5100	18L0042 No 83
Lexmark	X6170	18L0042 No 83
Lexmark	X6190 Pro	18L0042 No 83
Lexmark	Z55	18L0042 No 83
Lexmark	Z65	18L0042 No 83
Lexmark	Z65 Pro	18L0042 No 83
Lexmark	Z55se	18L0042 No 83
Compaq	A900	12A1980 No 80
Kodak	Personal Picturemaker 10	12A1980 No 80
Lexmark	3000	12A1980 No 80
Lexmark	3200	12A1980 No 80
Lexmark	5000	12A1980 No 80
Lexmark	5700	12A1980 No 80
Lexmark	5770	12A1980 No 80
Lexmark	7000	12A1980 No 80
Lexmark	7200	12A1980 No 80
Lexmark	7200V	12A1980 No 80
Lexmark	ColorJet 3200	12A1980 No 80
Lexmark	ColorJet 5700	12A1980 No 80
Lexmark	ColorJet 5770	12A1980 No 80
Lexmark	ColorJet 7000	12A1980 No 80
Lexmark	ColorJet 7200	12A1980 No 80
Lexmark	ColorJet 7200v	12A1980 No 80
Lexmark	Optra Color 40	12A1980 No 80
Lexmark	Optra Color 40n	12A1980 No 80
Lexmark	Optra Color 45	12A1980 No 80
Lexmark	Z11	12A1980 No 80
Lexmark	Z31	12A1980 No 80
Samsung	MJ 4500C	12A1980 No 80
Samsung	SCX 1150F	12A1980 No 80
Samsung	SF 4300	12A1980 No 80
Samsung	SF 4300C	12A1980 No 80
Samsung	SF 4500 Series	12A1980 No 80
Samsung	Msys 4700	12A1980 No 80
Compaq	IJ 600	17G0060E No 60
Lexmark	Z32	17G0060E No 60
Brother	Fax 1820C	LC800Y

Brother	MFC 3220CN	LC800Y
Brother	MFC 3320CN	LC800Y
Brother	MFC 3820CN	LC800Y
Brother	MFC 3420C	LC800Y
Brother	DCP 110C	LC900Y
Brother	DCP 315CN	LC900Y
Brother	Fax 1840C	LC900Y
Brother	Fax 1840CU1	LC900Y
Brother	Fax 1940CN	LC900Y
Brother	Fax 2240C	LC900Y
Brother	Fax 2440C	LC900Y
Brother	MFC 210C	LC900Y
Brother	MFC 215C	LC900Y
Brother	MFC 3240C	LC900Y
Brother	MFC 3340CN	LC900Y
Brother	MFC 410CN	LC900Y
Brother	MFC 425CN	LC900Y
Brother	MFC 5440CN	LC900Y
Brother	MFC 5840CN	LC900Y
Brother	MFC 620CN	LC900Y
Brother	MFC 5540	LC900Y
Brother	MFC 3100C	LC600Y
Brother	MFC 5200C	LC600Y
Brother	MFC 580	LC600Y
Brother	MFC 590	LC600Y
Brother	DCP 4020C	LC700Y
Hewlett Packard (HP)	Business InkJet 2200	C4813A no 11y
Hewlett Packard (HP)	Color InkJet Printer cp170	C4813A no 11y
Hewlett Packard (HP)	OfficeJet 9110	C4813A no 11y
Hewlett Packard (HP)	OfficeJet 9120	C4813A no 11y
Hewlett Packard (HP)	OfficeJet 9130	C4813A no 11y
Hewlett Packard (HP)	Business InkJet 1000	C4813A no 11y
Hewlett Packard (HP)	Business InkJet 1200d	C4813A no 11y
Hewlett Packard (HP)	Business InkJet 2800	C4813A no 11y
Hewlett Packard (HP)	Business InkJet 2800DT	C4813A no 11y
Hewlett Packard (HP)	Business InkJet 2800DTN	C4813A no 11y
Hewlett Packard (HP)	Business InkJet 2300	C4813A no 11y
Hewlett Packard (HP)	Business InkJet 2300n	C4813A no 11y
Hewlett Packard (HP)	Business InkJet 2300dtn	C4813A no 11y
Hewlett Packard (HP)	OfficeJet Pro K850	C4813A no 11y
Hewlett Packard (HP)	OfficeJet Pro K850dn	C4813A no 11y
Hewlett Packard (HP)	DesignJet 100	C4813A no 11y
Hewlett Packard (HP)	DesignJet 500	C4913A no 82
Hewlett Packard (HP)	Officejet Pro K550	C9393A No 88yw
Hewlett Packard (HP)	Officejet Pro L7580	C9393A No 88yw
Hewlett Packard (HP)	Officejet Pro L7480	C9393A No 88yw
Hewlett Packard (HP)	OfficeJet Pro L7590	C9393A No 88yw
Hewlett Packard (HP)	OfficeJet Pro K8600	C9393A No 88yw
Brother	DCP 130C	LC1000Y
Brother	FAX 2480C	LC1000Y

Brother	MFC 240C	LC1000Y
Brother	MFC 3360C	LC1000Y
Brother	MFC 440CN	LC1000Y
Brother	MFC 5460CN	LC1000Y
Brother	MFC 5860CN	LC1000Y
Brother	MFC 660CN	LC1000Y
Brother	MFC 665CW	LC1000Y
Brother	MFC 845CW	LC1000Y
Brother	DCP 357C	LC1000Y
Brother	DCP 560CN	LC1000Y
Brother	DCP 770CW	LC1000Y
Hewlett Packard (HP)	OfficeJet J5780	CB337EE No 351
Hewlett Packard (HP)	Photosmart C4580 All-in-	CB337EE No 351
Hewlett Packard (HP)	OfficeJet J6410 All in One	CB337EE No 351
Hewlett Packard (HP)	OfficeJet J6424	CB337EE No 351
Hewlett Packard (HP)	DeskJet D4360	CB337EE No 351
Hewlett Packard (HP)	PhotoSmart D5360	CB337EE No 351
Hewlett Packard (HP)	Photosmart C4270	CB337EE No 351
Hewlett Packard (HP)	Photosmart C4380	CB337EE No 351
Hewlett Packard (HP)	PhotoSmart C4480	CB337EE No 351
Hewlett Packard (HP)	OfficeJet J5780	CB338EE No 351xl
Hewlett Packard (HP)	Photosmart C5280	CB338EE No 351xl
Hewlett Packard (HP)	OfficeJet 5700	CB338EE No 351xl
Hewlett Packard (HP)	Photosmart C4472	CB338EE No 351xl
Hewlett Packard (HP)	Photosmart C4200	CB338EE No 351xl
Hewlett Packard (HP)	Photosmart C4580 All-in-	CB338EE No 351xl
Hewlett Packard (HP)	OfficeJet J6410 All in One	CB338EE No 351xl
Hewlett Packard (HP)	OfficeJet J6424	CB338EE No 351xl
Hewlett Packard (HP)	DeskJet D4360	CB338EE No 351xl
Hewlett Packard (HP)	PhotoSmart D5360	CB338EE No 351xl
Hewlett Packard (HP)	Photosmart C4270	CB338EE No 351xl
Hewlett Packard (HP)	Photosmart C4380	CB338EE No 351xl
Hewlett Packard (HP)	PhotoSmart C4480	CB338EE No 351xl
Brother	DCP 135C	LC970Y
Brother	MFC 235C	LC970Y
Brother	MFC 260C	LC970Y
Brother	MFC 465CN	LC970Y
Hewlett Packard (HP)	DeskJet D2560	CC643EE No 300
Hewlett Packard (HP)	DeskJet D5560	CC643EE No 300
Hewlett Packard (HP)	PhotoSmart C4680 AIO	CC643EE No 300
Hewlett Packard (HP)	DeskJet D1660	CC643EE No 300
Hewlett Packard (HP)	DeskJet D2660	CC643EE No 300
Hewlett Packard (HP)	PhotoSmart C4780 AIO	CC643EE No 300
Hewlett Packard (HP)	PhotoSmart C5300 All in c	CB320E No 364yw
Hewlett Packard (HP)	PhotoSmart B8550	CB320E No 364yw
Hewlett Packard (HP)	Photosmart C5383	CB320E No 364yw
Hewlett Packard (HP)	Photosmart C5380	CB320E No 364yw
Hewlett Packard (HP)	Photosmart C6380	CB320E No 364yw
Hewlett Packard (HP)	PhotoSmart B8553	CB320E No 364yw
Hewlett Packard (HP)	PhotoSmart D7560	CB320E No 364yw

Hewlett Packard (HP)	PhotoSmart C6300	CB320E No 364yw
Hewlett Packard (HP)	PhotoSmart Q8433B	CB320E No 364yw
Hewlett Packard (HP)	PhotoSmart 6510 AIO	CB320E No 364yw
Canon	Pixma IP3600	CLI-521y
Canon	Pixma MP550	CLI-521y
Canon	Pixma MP560	CLI-521y
Canon	Pixma MP640	CLI-521y
Canon	Pixma IP4700	CLI-521y
Canon	Pixma MP240	CL-513
Canon	Pixma MP270	CL-513
Canon	Pixma MP480	CL-513
Canon	Pixma iP2700	CL-513
Canon	PIXMA MP490	CL-513
Canon	PIXMA MP495	CL-513
Canon	PIXMA MX340	CL-513
Canon	Pixma IP2702	CL-513
Canon	Pixma MX410	CL-513
Canon	PIXMA MP280	CL-513
Canon	Pixma MP230	CL-513
Brother	DCP 145C	LC980Y
Brother	DCP 385C	LC1100Y
Canon	Pixma IP1900	CL-38
Canon	Pixma IP2600	CL-38
Canon	Pixma MP190	CL-38
Canon	Pixma MX300	CL-38
Hewlett Packard (HP)	F4280 All in one	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet 3910	C9352CE No 22XL
Hewlett Packard (HP)	DeskJet D1368	C9352CE No 22XL
Hewlett Packard (HP)	DeskJet F310	C9352CE No 22XL
Hewlett Packard (HP)	DeskJet F380	C9352CE No 22XL
Hewlett Packard (HP)	DeskJet F385	C9352CE No 22XL
Hewlett Packard (HP)	DeskJet F388	C9352CE No 22XL
Hewlett Packard (HP)	OfficeJet 4355	C9352CE No 22XL
Hewlett Packard (HP)	PSC 1403	C9352CE No 22XL
Hewlett Packard (HP)	DeskJet F2180	C9352CE No 22XL
Hewlett Packard (HP)	DeskJet D1560	C9352CE No 22XL
Hewlett Packard (HP)	DeskJet F2280	C9352CE No 22XL
Hewlett Packard (HP)	DeskJet D1520	C9352CE No 22XL
Hewlett Packard (HP)	OfficeJet Pro 8500 AIO	C4909AE No 940XL
Lexmark	S305	14N0902E No 100yw
Lexmark	Pro 205	14N0902E No 100yw
Lexmark	Pro 705	14N0902E No 100yw
Lexmark	Pro 805	14N0902E No 100yw
Lexmark	Pro 905	14N0902E No 100yw
Lexmark	Interact S605	14N0902E No 100yw
Lexmark	S301	14N0902E No 100yw
Lexmark	S400	14N0902E No 100yw
Lexmark	S815	14N0902E No 100yw
Lexmark	S305	14N1071E No 100yw XL
Lexmark	Interact S605	14N1071E No 100yw XL

Lexmark	S301	14N1071E No 100yw XL
Lexmark	S400	14N1071E No 100yw XL
Lexmark	S815	14N1071E No 100yw XL
Canon	Pixma MP240	CL-511
Canon	Pixma MP250	CL-511
Canon	Pixma MP270	CL-511
Canon	Pixma MP480	CL-511
Canon	Pixma iP2700	CL-511
Canon	PIXMA MP490	CL-511
Canon	PIXMA MP495	CL-511
Canon	PIXMA MX340	CL-511
Canon	Pixma IP2702	CL-511
Canon	Pixma MX410	CL-511
Canon	PIXMA MP280	CL-511
Canon	Pixma MP230	CL-511
Canon	Pixma iP4850	CLI-526y
Canon	Pixma iP4950	CLI-526y
Brother	DCP J125	LC985Y
Brother	DCP J525W	LC1220Y
Brother	MFC J430W	LC1240CY
Canon	Pixma MG6350	CLI-551y
Canon	Pixma MG6350	CLI-551y XL
Canon	Pixma MG7150	CLI-551y XL
Canon	Pixma MG2450	CL-546
Canon	Pixma MG2450	CL-546XL
Hewlett Packard (HP)	Photosmart 6520	CB320E No 364yw
Hewlett Packard (HP)	Photosmart 7510	CB320E No 364yw
Hewlett Packard (HP)	Photosmart 7520	CB320E No 364yw
Hewlett Packard (HP)	Photosmart 7525	CB320E No 364yw
Canon	Pixma MG6450	CLI-551y
Canon	Pixma MG6450	CLI-551y XL
Hewlett Packard (HP)	PSC 1510	C9361E No 342
Hewlett Packard (HP)	PSC 1510 All-In-One	C8766E No 343
Canon	PIXMA MX495	CL-546
Canon	PIXMA MX495	CL-546XL
Hewlett Packard (HP)	PSC 1500	C9361E No 342
Canon	Pixma MG5650	CLI-551y
Canon	Pixma MG5650	CLI-551y XL
Canon	PIXMA iX6550	CLI-526y
Hewlett Packard (HP)	Designjet 510	C4913A no 82
Canon	Pixma MG6650	CLI-551y
Canon	Pixma MG6650	CLI-551y XL
Canon	PIXMA MG7550	CLI-551y
Canon	PIXMA MG7550	CLI-551y XL
Hewlett Packard (HP)	Deskjet F4580	CC643EE No 300
Hewlett Packard (HP)	Deskjet F4580	CC644EE No 300xl
Canon	Pixma MG2250	CL-541
Canon	Pixma MG2250	CL-541XL
Hewlett Packard (HP)	Officejet 5615	C9352A No 22
Hewlett Packard (HP)	Officejet 5615	C9352CE No 22XL

Hewlett Packard (HP)	DeskJet 2130 AIO	F6U65AE No 302col
Canon	Pixma MG5500	CLI-551y
Canon	Pixma MG5500	CLI-551y XL
Hewlett Packard (HP)	Photosmart 5510	CB320E No 364yw
Canon	Pixma MG3650	CL-541
Canon	Pixma MG3650	CL-541XL
Hewlett Packard (HP)	DeskJet 3630 AIO	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 3830 All in one	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 4650 All in one	F6U65AE No 302col
Hewlett Packard (HP)	ENVY 4520 AIO	F6U65AE No 302col
Canon	Pixma MX870	CLI-521y
Hewlett Packard (HP)	Deskjet 3070A AIO	CB320E No 364yw
Hewlett Packard (HP)	PhotoSmart Wireless B11	CB320E No 364yw
Canon	Pixma MG2950	CL-546
Canon	Pixma MG2950	CL-546XL
Hewlett Packard (HP)	Officejet 4656 All in one	F6U65AE No 302col
Hewlett Packard (HP)	Photosmart Premium C31	CB320E No 364yw
Canon	Pixma MX455	CL-541
Canon	Pixma MX455	CL-541XL
Brother	MFC 295CN	LC980Y
Hewlett Packard (HP)	Photosmart Premium C30	CB320E No 364yw
Canon	Pixma MG3050	CL-546XL
Canon	Pixma MG3050	CL-546
Hewlett Packard (HP)	Photosmart C4100 Series	C8766E No 343
Hewlett Packard (HP)	Deskjet Ink Advantage 551	CZ112AE No 655yw
Canon	Pixma IP2850	CL-546XL
Canon	Pixma IP2850	CL-546
Hewlett Packard (HP)	DeskJet 5900 Series	C8766E No 343
Hewlett Packard (HP)	DeskJet 5900 Series	C9363E No 344
Hewlett Packard (HP)	Officejet 4620	CB320E No 364yw
Canon	Pixma MX353	CL-541
Canon	Pixma MX353	CL-541XL
Hewlett Packard (HP)	DeskJet 3639 AIO	F6U65AE No 302col
Hewlett Packard (HP)	DeskJet 1110	F6U65AE No 302col
Canon	Pixma MG3600	CL-541
Canon	Pixma MG3600	CL-541XL
Brother	MFC 5890CN	LC1100Y
Canon	Pixma MG2140	CL-541
Canon	Pixma MG3140	CL-541
Canon	Pixma MG2140	CL-541XL
Canon	Pixma MG3140	CL-541XL
Canon	Pixma MX885 AiO	CLI-526y
Canon	Pixma MX715 AiO	CLI-526y
Hewlett Packard (HP)	Photosmart 5515	CB320E No 364yw
Hewlett Packard (HP)	Photosmart Plus B210	CB320E No 364yw
Canon	Pixma MX535	CL-541
Canon	Pixma TS5150 AiO	CL-541
Canon	Pixma TS5151 AiO	CL-541
Canon	Pixma MX535	CL-541XL
Canon	Pixma TS5150 AiO	CL-541XL

Canon	Pixma TS5151 AiO	CL-541XL
Hewlett Packard (HP)	DesignJet 110 Plus NR	C4813A no 11y
Canon	PIXMA MX350	CL-513
Canon	Pixma MX420	CL-513
Canon	PIXMA MX360	CL-513
Canon	Pixma MP272	CL-513
Canon	PIXMA MX350	CL-511
Canon	Pixma MX420	CL-511
Canon	PIXMA MX360	CL-511
Canon	Pixma MP272	CL-511
Hewlett Packard (HP)	DeskJet Ink Advantage 11	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet Ink Advantage 46	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet Ink Advantage 36	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet Ink Advantage 50	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet Ink Advantage 52	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet Ink Advantage 37	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet Ink Advantage 37	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet Ink Advantage 21	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet Ink Advantage 37	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet Ink Advantage 37	F6V24AE No 652col
Canon	Pixma MG3550	CL-541
Canon	Pixma MG3550	CL-541XL
Canon	Pixma iP8750	CLI-551y
Canon	Pixma iX6850	CLI-551y
Canon	Pixma iP8750	CLI-551y XL
Canon	Pixma iX6850	CLI-551y XL
Brother	MFC J6710DW	LC1280XLY
Brother	MFC J6910DW	LC1280XLY
Brother	MFC J6510DW	LC1280XLY
Brother	MFC J5910DW	LC1280XLY
Brother	MFC J6510DW	LC1240CY
Brother	MFC J6710DW	LC1240CY
Brother	MFC J6910DW	LC1240CY
Brother	MFC J5910DW	LC1240CY
Canon	Pixma TS3151 AiO	CL-546
Canon	Pixma TS3150 AiO	CL-546
Canon	Pixma TR4551 AiO	CL-546
Canon	Pixma TR4550 AiO	CL-546
Canon	Pixma TS205	CL-546
Canon	Pixma TS305	CL-546
Canon	Pixma TS3151 AiO	CL-546XL
Canon	Pixma TS3150 AiO	CL-546XL
Canon	Pixma TR4551 AiO	CL-546XL
Canon	Pixma TR4550 AiO	CL-546XL
Canon	Pixma TS205	CL-546XL
Canon	Pixma TS305	CL-546XL
Hewlett Packard (HP)	DeskJet F2420 AiO	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F2420 AiO	CC643EE No 300
Hewlett Packard (HP)	Deskjet F2480 AiO	CC643EE No 300
Hewlett Packard (HP)	DeskJet F2400 AiO series	CC643EE No 300

Hewlett Packard (HP)	DeskJet F2410 AiO	CC643EE No 300
Hewlett Packard (HP)	DeskJet F2418 AiO	CC643EE No 300
Hewlett Packard (HP)	DeskJet F2423 AiO	CC643EE No 300
Hewlett Packard (HP)	DeskJet F2430 AiO	CC643EE No 300
Hewlett Packard (HP)	DeskJet F2440 AiO	CC643EE No 300
Hewlett Packard (HP)	DeskJet F2476 AiO	CC643EE No 300
Hewlett Packard (HP)	DeskJet F2483 AiO	CC643EE No 300
Hewlett Packard (HP)	DeskJet F2488 AiO	CC643EE No 300
Hewlett Packard (HP)	DeskJet F2492 AiO	CC643EE No 300
Hewlett Packard (HP)	DeskJet F2493 AiO	CC643EE No 300
Hewlett Packard (HP)	Deskjet F2480 AiO	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F2400 AiO series	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F2410 AiO	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F2418 AiO	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F2423 AiO	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F2430 AiO	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F2440 AiO	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F2476 AiO	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F2483 AiO	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F2488 AiO	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F2492 AiO	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F2493 AiO	CC644EE No 300xl
Lexmark	X5495	18C0035E No 35
Hewlett Packard (HP)	DeskJet 2630 AIO	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 3720 AiO	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 3730	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 3733	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 3735	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 3750	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 2630 AIO	N9K07AE No 304XL col
Hewlett Packard (HP)	DeskJet 3720 AiO	N9K07AE No 304XL col
Hewlett Packard (HP)	DeskJet 2620 AIO	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 3760	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 3762	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 3764	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 2622	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 2632	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 2633	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 2634	N9K05AE No 304col
Hewlett Packard (HP)	ENVY 5010 AiO	N9K05AE No 304col
Hewlett Packard (HP)	ENVY 5012 AiO	N9K05AE No 304col
Hewlett Packard (HP)	ENVY 5020 AiO	N9K05AE No 304col
Hewlett Packard (HP)	ENVY 5030 AiO	N9K05AE No 304col
Hewlett Packard (HP)	ENVY 5032 AiO	N9K05AE No 304col
Hewlett Packard (HP)	ENVY 5055 AiO	N9K05AE No 304col
Hewlett Packard (HP)	HP AMP 130	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 2620 AIO	N9K07AE No 304XL col
Hewlett Packard (HP)	DeskJet 3730	N9K07AE No 304XL col
Hewlett Packard (HP)	DeskJet 3733	N9K07AE No 304XL col
Hewlett Packard (HP)	DeskJet 3735	N9K07AE No 304XL col

Hewlett Packard (HP)	DeskJet 3750	N9K07AE No 304XL col
Hewlett Packard (HP)	DeskJet 3760	N9K07AE No 304XL col
Hewlett Packard (HP)	DeskJet 3762	N9K07AE No 304XL col
Hewlett Packard (HP)	DeskJet 3764	N9K07AE No 304XL col
Hewlett Packard (HP)	DeskJet 2622	N9K07AE No 304XL col
Hewlett Packard (HP)	DeskJet 2632	N9K07AE No 304XL col
Hewlett Packard (HP)	DeskJet 2633	N9K07AE No 304XL col
Hewlett Packard (HP)	DeskJet 2634	N9K07AE No 304XL col
Hewlett Packard (HP)	ENVY 5010 AiO	N9K07AE No 304XL col
Hewlett Packard (HP)	ENVY 5012 AiO	N9K07AE No 304XL col
Hewlett Packard (HP)	ENVY 5020 AiO	N9K07AE No 304XL col
Hewlett Packard (HP)	ENVY 5030 AiO	N9K07AE No 304XL col
Hewlett Packard (HP)	ENVY 5032 AiO	N9K07AE No 304XL col
Hewlett Packard (HP)	ENVY 5055 AiO	N9K07AE No 304XL col
Hewlett Packard (HP)	HP AMP 130	N9K07AE No 304XL col
Hewlett Packard (HP)	DeskJet 3520 e-All-in-One	CB320E No 364yw
Hewlett Packard (HP)	DeskJet 1112	F6U65AE No 302col
Hewlett Packard (HP)	DeskJet 2131 AIO	F6U65AE No 302col
Hewlett Packard (HP)	DeskJet 2132 AIO	F6U65AE No 302col
Hewlett Packard (HP)	DeskJet 2134 AIO	F6U65AE No 302col
Hewlett Packard (HP)	DeskJet 2136 AIO	F6U65AE No 302col
Hewlett Packard (HP)	ENVY 4511 AIO	F6U65AE No 302col
Hewlett Packard (HP)	ENVY 4512 AIO	F6U65AE No 302col
Hewlett Packard (HP)	ENVY 4513 AIO	F6U65AE No 302col
Hewlett Packard (HP)	ENVY 4516 AIO	F6U65AE No 302col
Hewlett Packard (HP)	ENVY 4521 AIO	F6U65AE No 302col
Hewlett Packard (HP)	ENVY 4522 AIO	F6U65AE No 302col
Hewlett Packard (HP)	ENVY 4523 AIO	F6U65AE No 302col
Hewlett Packard (HP)	ENVY 4524 AIO	F6U65AE No 302col
Hewlett Packard (HP)	ENVY 4525 AIO	F6U65AE No 302col
Hewlett Packard (HP)	ENVY 4526 AIO	F6U65AE No 302col
Hewlett Packard (HP)	ENVY 4527 AIO	F6U65AE No 302col
Hewlett Packard (HP)	ENVY 4528 AIO	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 3831 AiO	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 3832 AiO	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 3833 AiO	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 3834 AiO	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 4652 AiO	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 4654 AiO	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 4655 AiO	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 4656 AiO	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 4657 AiO	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 5220 AiO	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 5230 AiO	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 5258 AiO	F6U65AE No 302col
Hewlett Packard (HP)	DeskJet Ink Advantage 38	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet Ink Advantage 38	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet Ink Advantage 38	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet Ink Advantage 38	F6V24AE No 652col
Hewlett Packard (HP)	DesignJet 800	C4813A no 11y

Hewlett Packard (HP)	Designjet 510	C4813A no 11y
Hewlett Packard (HP)	DeskJet 2600 AIO	N9K05AE No 304col
Hewlett Packard (HP)	DeskJet 2600 AIO	N9K07AE No 304XL col
Hewlett Packard (HP)	PhotoSmart B010a	CB320E No 364yw
Hewlett Packard (HP)	DeskJet 3637	F6U65AE No 302col
Hewlett Packard (HP)	DeskJet 3636	F6U65AE No 302col
Hewlett Packard (HP)	Officejet 100 Mobile Print	C8766E No 343
Hewlett Packard (HP)	Officejet 100 Mobile Print	C9363E No 344
Hewlett Packard (HP)	Photosmart B109	CB320E No 364yw
Hewlett Packard (HP)	Deskjet Ink Advantage 46	CZ112AE No 655yw
Hewlett Packard (HP)	Deskjet Ink Advantage 46	CZ112AE No 655yw
Hewlett Packard (HP)	Deskjet Ink Advantage 35	CZ112AE No 655yw
Hewlett Packard (HP)	Deskjet Ink Advantage 65	CZ112AE No 655yw
Hewlett Packard (HP)	Deskjet Ink Advantage 45	F6V24AE No 652col
Hewlett Packard (HP)	Deskjet Ink Advantage 45	F6V24AE No 652col
Hewlett Packard (HP)	Deskjet Ink Advantage 45	F6V24AE No 652col
Hewlett Packard (HP)	OfficeJet K7103	C8766E No 343
Hewlett Packard (HP)	OfficeJet K7103	C9363E No 344
Canon	Pixma TS3350 AiO	CL-546
Canon	Pixma TS3355 AiO	CL-546
Canon	Pixma TS3350 AiO	CL-546XL
Canon	Pixma TS3355 AiO	CL-546XL
Hewlett Packard (HP)	Photosmart 5524	CB320E No 364yw
Hewlett Packard (HP)	DeskJet F2187 AiO	C9352A No 22
Hewlett Packard (HP)	DeskJet F2187 AiO	C9352CE No 22XL
Canon	Pixma MX475	CL-541
Canon	Pixma MX525	CL-541
Canon	Pixma MX395	CL-541
Canon	Pixma MX475	CL-541XL
Canon	Pixma MX525	CL-541XL
Canon	Pixma MX395	CL-541XL
Canon	Pixma TS3352 AiO	CL-546
Canon	Pixma TS3352 AiO	CL-546XL
Brother	MFC 5895CW	LC1100Y
Hewlett Packard (HP)	DeskJet D1600 Printer ser	CC643EE No 300
Hewlett Packard (HP)	DeskJet D1600 Printer ser	CC644EE No 300xl
Canon	Pixma MG3053	CL-546
Canon	Pixma MG3053	CL-546XL
Hewlett Packard (HP)	DeskJet Ink Advantage 37	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet Ink Advantage 37	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet F4272 All in one	CC643EE No 300
Hewlett Packard (HP)	DeskJet F4273 All in one	CC643EE No 300
Hewlett Packard (HP)	DeskJet F4274 All in one	CC643EE No 300
Hewlett Packard (HP)	DeskJet F4280 All in one	CC643EE No 300
Hewlett Packard (HP)	DeskJet F4293 All in one	CC643EE No 300
Hewlett Packard (HP)	DeskJet F4272 All in one	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F4273 All in one	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F4274 All in one	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F4280 All in one	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet F4293 All in one	CC644EE No 300xl

Canon	Pixma TS3451 AiO	CL-546
Canon	Pixma TS3351 AiO	CL-546
Canon	Pixma TS3452 AiO	CL-546
Canon	Pixma TS3451 AiO	CL-546XL
Canon	Pixma TS3351 AiO	CL-546XL
Canon	Pixma TS3452 AiO	CL-546XL
Hewlett Packard (HP)	Photosmart 5520	CB320E No 364yw
Hewlett Packard (HP)	Photosmart Plus B209	CB320E No 364yw
Hewlett Packard (HP)	DeskJet 2710 AiO	3YM60AE No 305 Col
Hewlett Packard (HP)	DeskJet 2720 series	3YM60AE No 305 Col
Hewlett Packard (HP)	DeskJet Plus 4120 AiO ser	3YM63AE No 305XL Col
Hewlett Packard (HP)	DeskJet 2710 AiO	3YM63AE No 305XL Col
Hewlett Packard (HP)	DeskJet 2720 series	3YM63AE No 305XL Col
Hewlett Packard (HP)	DeskJet Plus 4110	3YM63AE No 305XL Col
Hewlett Packard (HP)	DeskJet Plus 4130	3YM63AE No 305XL Col
Hewlett Packard (HP)	ENVY 6000 AiO series	3YM63AE No 305XL Col
Hewlett Packard (HP)	DeskJet 2320 AiO	3YM63AE No 305XL Col
Hewlett Packard (HP)	ENVY 6020 AiO	3YM63AE No 305XL Col
Hewlett Packard (HP)	ENVY 6022 AiO	3YM63AE No 305XL Col
Hewlett Packard (HP)	ENVY 6030 AiO	3YM63AE No 305XL Col
Hewlett Packard (HP)	ENVY 6032 AiO	3YM63AE No 305XL Col
Hewlett Packard (HP)	ENVY 6052 AiO	3YM63AE No 305XL Col
Hewlett Packard (HP)	DeskJet Plus 4120 AiO ser	3YM60AE No 305 Col
Hewlett Packard (HP)	DeskJet Plus 4110	3YM60AE No 305 Col
Hewlett Packard (HP)	DeskJet Plus 4130	3YM60AE No 305 Col
Hewlett Packard (HP)	ENVY 6000 AiO series	3YM60AE No 305 Col
Hewlett Packard (HP)	DeskJet 2320 AiO	3YM60AE No 305 Col
Hewlett Packard (HP)	ENVY 6020 AiO	3YM60AE No 305 Col
Hewlett Packard (HP)	ENVY 6022 AiO	3YM60AE No 305 Col
Hewlett Packard (HP)	ENVY 6030 AiO	3YM60AE No 305 Col
Hewlett Packard (HP)	ENVY 6032 AiO	3YM60AE No 305 Col
Hewlett Packard (HP)	ENVY 6052 AiO	3YM60AE No 305 Col
Hewlett Packard (HP)	DeskJet D4200	CB337EE No 351
Hewlett Packard (HP)	DeskJet D4200	CB338EE No 351xl
Hewlett Packard (HP)	DeskJet 2721e AiO	3YM63AE No 305XL Col
Hewlett Packard (HP)	ENVY Pro 6420e AiO	3YM63AE No 305XL Col
Hewlett Packard (HP)	DeskJet 2721e AiO	3YM60AE No 305 Col
Hewlett Packard (HP)	ENVY Pro 6420e AiO	3YM60AE No 305 Col
Canon	Pixma MG6250	CLI-526y
Hewlett Packard (HP)	ENVY 120 AIO	CC643EE No 300
Hewlett Packard (HP)	ENVY 110 AIO	CC643EE No 300
Hewlett Packard (HP)	ENVY 100 AIO	CC643EE No 300
Hewlett Packard (HP)	ENVY 120 AIO	CC644EE No 300xl
Hewlett Packard (HP)	ENVY 110 AIO	CC644EE No 300xl
Hewlett Packard (HP)	ENVY 100 AIO	CC644EE No 300xl
Canon	Pixma TS3450 AiO	CL-546
Canon	Pixma TR4650 AiO	CL-546
Canon	Pixma TR4651 AiO	CL-546
Canon	Pixma TS3450 AiO	CL-546XL
Canon	Pixma TR4650 AiO	CL-546XL

Canon	Pixma TR4651 AiO	CL-546XL
Hewlett Packard (HP)	DeskJet D2560	CC644EE No 300xl
Hewlett Packard (HP)	DeskJet Plus 4122e AiO	3YM63AE No 305XL Col
Hewlett Packard (HP)	DeskJet Plus 4100 AiO ser	3YM63AE No 305XL Col
Hewlett Packard (HP)	DeskJet Plus 4122e AiO	3YM60AE No 305 Col
Hewlett Packard (HP)	DeskJet Plus 4100 AiO ser	3YM60AE No 305 Col
Hewlett Packard (HP)	DeskJet 2723e AiO	3YM63AE No 305XL Col
Hewlett Packard (HP)	DeskJet 2723e AiO	3YM60AE No 305 Col
Canon	Pixma MX925	CLI-551y
Canon	Pixma MX925	CLI-551y XL
Hewlett Packard (HP)	DeskJet Ink Advantage 21	F6V24AE No 652col
Hewlett Packard (HP)	DeskJet 2720 AIO	3YM63AE No 305XL Col
Hewlett Packard (HP)	DeskJet 2721 AIO	3YM63AE No 305XL Col
Hewlett Packard (HP)	DeskJet 2700 series	3YM63AE No 305XL Col
Hewlett Packard (HP)	DeskJet 2720 AIO	3YM60AE No 305 Col
Hewlett Packard (HP)	DeskJet 2721 AIO	3YM60AE No 305 Col
Hewlett Packard (HP)	DeskJet 2700 series	3YM60AE No 305 Col