

Brand	Model	Original Cartridge
HP	DeskJet 450	C6657A No 57
HP	DeskJet 450cbi	C6657A No 57
HP	DeskJet 450ci	C6657A No 57
HP	DeskJet 450wbt	C6657A No 57
HP	DeskJet 5150	C6657A No 57
HP	DeskJet 5151	C6657A No 57
HP	DeskJet 5550	C6657A No 57
HP	DeskJet 5551	C6657A No 57
HP	DeskJet 5552	C6657A No 57
HP	DeskJet 5600	C6657A No 57
HP	DeskJet 5650	C6657A No 57
HP	DeskJet 5652	C6657A No 57
HP	DeskJet 5655	C6657A No 57
HP	DeskJet 5850	C6657A No 57
HP	DeskJet 6110	C6657A No 57
HP	DeskJet 7762	C6657A No 57
HP	DeskJet 9600	C6657A No 57
HP	DeskJet 9650	C6657A No 57
HP	DeskJet 9670	C6657A No 57
HP	DeskJet 9680	C6657A No 57
HP	DeskJet F4172	C6657A No 57
HP	Digital Copier 410	C6657A No 57
HP	Digital Copier Printer 410	C6657A No 57
HP	Fax 1240	C6657A No 57
HP	OfficeJet 4110	C6657A No 57
HP	OfficeJet 4200	C6657A No 57
HP	OfficeJet 4215	C6657A No 57
HP	OfficeJet 4219	C6657A No 57
HP	OfficeJet 4255	C6657A No 57
HP	OfficeJet 5500	C6657A No 57
HP	OfficeJet 5505	C6657A No 57
HP	OfficeJet 5510	C6657A No 57
HP	OfficeJet 5515	C6657A No 57
HP	OfficeJet 6110	C6657A No 57
HP	PhotoSmart 100	C6657A No 57
HP	PhotoSmart 130	C6657A No 57
HP	PhotoSmart 140	C6657A No 57
HP	PhotoSmart 145	C6657A No 57
HP	PhotoSmart 230	C6657A No 57
HP	PhotoSmart 240	C6657A No 57
HP	PhotoSmart 2410	C6657A No 57
HP	PhotoSmart 245	C6657A No 57
HP	PhotoSmart 2500	C6657A No 57
HP	PhotoSmart 2510	C6657A No 57
HP	PhotoSmart 7150	C6657A No 57
HP	PhotoSmart 7200	C6657A No 57
HP	PhotoSmart 7260	C6657A No 57
HP	PhotoSmart 7345	C6657A No 57
HP	PhotoSmart 7350	C6657A No 57

HP	PhotoSmart 7400 Series	C6657A No 57
HP	PhotoSmart 7450	C6657A No 57
HP	PhotoSmart 7450v	C6657A No 57
HP	PhotoSmart 7450xi	C6657A No 57
HP	PhotoSmart 7550	C6657A No 57
HP	PhotoSmart 7600	C6657A No 57
HP	PhotoSmart 7660	C6657A No 57
HP	PhotoSmart 7700	C6657A No 57
HP	PhotoSmart 7755	C6657A No 57
HP	PhotoSmart 7760	C6657A No 57
HP	PhotoSmart 7762	C6657A No 57
HP	PhotoSmart 7900	C6657A No 57
HP	PhotoSmart 7960	C6657A No 57
HP	PhotoSmart P145	C6657A No 57
HP	PhotoSmart P230	C6657A No 57
HP	PhotoSmart P7150	C6657A No 57
HP	PSC 1100	C6657A No 57
HP	PSC 1110	C6657A No 57
HP	PSC 1200	C6657A No 57
HP	PSC 1205	C6657A No 57
HP	PSC 1209	C6657A No 57
HP	PSC 1210	C6657A No 57
HP	PSC 1213	C6657A No 57
HP	PSC 1215	C6657A No 57
HP	PSC 1217	C6657A No 57
HP	PSC 1219	C6657A No 57
HP	PSC 1300	C6657A No 57
HP	PSC 1310	C6657A No 57
HP	PSC 1311	C6657A No 57
HP	PSC 1315	C6657A No 57
HP	PSC 1317	C6657A No 57
HP	PSC 1340	C6657A No 57
HP	PSC 1350	C6657A No 57
HP	PSC 1355	C6657A No 57
HP	PSC 2108	C6657A No 57
HP	PSC 2110	C6657A No 57
HP	PSC 2110v	C6657A No 57
HP	PSC 2110xi	C6657A No 57
HP	PSC 2115	C6657A No 57
HP	PSC 2170	C6657A No 57
HP	PSC 2171	C6657A No 57
HP	PSC 2175	C6657A No 57
HP	PSC 2179	C6657A No 57
HP	PSC 2210	C6657A No 57
HP	PSC 2410	C6657A No 57
HP	PSC 2410 PhotoSmart	C6657A No 57
HP	PSC 2510	C6657A No 57
HP	PSC 2510 PhotoSmart	C6657A No 57
HP	PSC 2550	C6657A No 57
HP	PSC 4110	C6657A No 57

HP	PSC 4215	C6657A No 57
HP	PSC 4219	C6657A No 57
HP	PSC 4255	C6657A No 57