

Brand	Model	Original Cartridge
Epson	EcoTank L1110	C13T00S14A 103 black
Epson	EcoTank L1210	C13T00S14A 103 black
Epson	EcoTank L1250	C13T00S14A 103 black
Epson	EcoTank L3110	C13T00S14A 103 black
Epson	EcoTank L3111	C13T00S14A 103 black
Epson	EcoTank L3150 MFP	C13T00S14A 103 black
Epson	EcoTank L3151 WiFi MFP	C13T00S14A 103 black
Epson	EcoTank L3156 WiFi MFP	C13T00S14A 103 black
Epson	EcoTank L3160 MFP	C13T00S14A 103 black
Epson	EcoTank L3210	C13T00S14A 103 black
Epson	EcoTank L3211	C13T00S14A 103 black
Epson	EcoTank L3250 WiFi MFP	C13T00S14A 103 black
Epson	EcoTank L3251	C13T00S14A 103 black
Epson	EcoTank L3256	C13T00S14A 103 black
Epson	EcoTank L3260 WiFi MFP	C13T00S14A 103 black
Epson	EcoTank L3266	C13T00S14A 103 black
Epson	EcoTank L3550	C13T00S14A 103 black
Epson	EcoTank L3560 WiFi MFP	C13T00S14A 103 black
Epson	EcoTank L5190	C13T00S14A 103 black
Epson	EcoTank L5290	C13T00S14A 103 black
Epson	EcoTank L5296	C13T00S14A 103 black
Epson	EcoTank L5590	C13T00S14A 103 black